

8990B-02

Modification Recommended Service Note

Supersedes:
NONE

8990B-Peak Power Analyzer

Serial Numbers: ALL

“Unresponsive knobs” on 8990B front panel.

Parts Required:

P/N	Description	Qty.
54904-66405	PCA-Front Panel	1

ADMINISTRATIVE INFORMATION

ACTION	<input checked="" type="checkbox"/> ON SPECIFIED FAILURE	STANDARDS			
CATEGORY:	<input type="checkbox"/> AGREEABLE TIME	LABOR:	1.0 Hours		
LOCATION	<input type="checkbox"/> CUSTOMER INSTALLABLE	SERVICE	<input type="checkbox"/> RETURN	USED	<input checked="" type="checkbox"/> RETURN
CATEGORY:	<input type="checkbox"/> ON-SITE (active On-site contract required)	INVENTORY:	<input type="checkbox"/> SCRAP	PARTS:	<input type="checkbox"/> SCRAP
	<input checked="" type="checkbox"/> SERVICE CENTER		<input checked="" type="checkbox"/> SEE TEXT		<input type="checkbox"/> SEE TEXT
	<input type="checkbox"/> CHANNEL PARTNERS				
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	NO CHARGE AVAILABLE UNTIL:	(EOS)		
	<input type="checkbox"/> Calibration Required	PRODUCT LINE:	[WC]		
	<input checked="" type="checkbox"/> Calibration NOT Required	AUTHOR:	[Janise Lim]		

ADDITIONAL INFORMATION:

Service inventory : N/A



Situation:

Customers may experience unresponsive knobs on 8990B front panel intermittently. The unit can recover by power cycle the 8990B. This is a temporary workaround but customer may encounter the knob being unresponsive again during usage.



Solution/Action:


Contact the nearest Service Center to have the unit serviced.

Instruction to Service Centers

1. Replace the Front Panel keyboard Assembly 54904-66405.
2. Run front panel test (Tools -> Front Panel Test), press default setup, then close Peak Power Analyzer application and re-open the application.
3. Age the unit for 24 hours.
4. After 24 hours, then repeat step 2.
5. Rotate the knob multiple turns in both directions (clockwise and anti-clockwise) to check its response. You may follow the inspection with the table 1:

Table 1: Front panel knob repeatability test for PPA level

Knob	Rotation	PPA application
Horizontal scale knob	Clockwise	Continuously rotate knob until message prompted “Application: The Time Scale control is at its minimum limit”
	Anticlockwise	Continuously rotate knob until message prompted “Application: The Time Scale control is at its maximum limit”
Horizontal position knob	Clockwise	Continuously rotate knob for until horizontal position reach/exceed -50us. 
	Anticlockwise	Continuously rotate knob for until horizontal position reach/exceed 50us. 
Trigger level knob	Clockwise	Continuously rotate knob until message prompted “Application: The Trigger Level control is at its maximum limit”
	Anticlockwise	Continuously rotate knob until message prompted “Application: The Trigger Level control is at its minimum limit”

Measure position knob	Clockwise	Press on Markers. Select “Free Float” from drop down list. Tick “Search A” or “Search B”. Click “Close”.
	Anticlockwise	 <p>Push on Measure position knob to select the marker A/B. Rotate knob along axis on display.</p>
Channel vertical scale knob <i>(*NOTE: Repeat for each channel)</i>	Clockwise	Continuously rotate knob until message prompted “Application: The Channel Scale control is at its minimum limit”
	Anticlockwise	Continuously rotate knob until message prompted “Application: The Channel Scale control is at its maximum limit”
Channel vertical offset knob <i>(*NOTE: Repeat for each channel)</i>	Clockwise	Continuously rotate knob for each channel until message prompted “Application: The Channel Reference control is at its minimum limit”
	Anticlockwise	Continuously rotate knob for each channel until message prompted “Application: The Channel Reference control is at its maximum limit”

Revision History:

Date	Service Note Revision	Author	Reason for Change
07 Oct 2015	01	Janise Lim	As Published