

HP MODEL 8690A SWEEP OSCILLATORS

All Serials

REPLACEMENT PUSHBUTTONS

The recommended replacements for the pushbutton switches S4, S5, S6, S7, and S8 in HP Model 8690A Sweep Oscillators, all Serials, is HP Part Number 3101-1153.

The new switch is more reliable than the old switch. It is a direct replacement except that when replacing S8, the EXT AM switch, the new switch must be mounted upside down to clear the R. F. UNIT.

9/67-4