HEWLETT - PACKARD LIBRARY

**APPLICATION NOTE 140-7** 


REFERENCE COPY

NOT TO BE DO NOT REMOVE

# **Nuclear Power Plant Diagnostics Using Fourier Analysis Techniques**

## Summary of this Note

This note describes application of Fourier Analysis techniques to nuclear power plant diagnostics. Reactor core measurements discussed include: a) detection of core component vibration, b) detection of core motion, c) detection of departure from nucleate boiling. Other reactor plant measurements discussed include: a) measurement of vibrations of rotating machinery, b) seismic measurements, c) modal analysis of vibrating pipes.





# NUCLEAR POWER PLANT DIAGNOSTICS USING FOURIER ANALYSIS TECHNIQUES

by

MITTY C. PLUMMER
Nuclear Services Corporation
477 Division St.
Campbell, California

#### INTRODUCTION

This note describes application of Fourier Analysis techniques to nuclear power plant diagnostics. Both reactor and balance of plant applications are discussed. Reactor applications are identified separately from balance of plant and receive greater emphasis because two recent technological advances have greatly increased the utility of neutron noise analysis for power reactor diagnostics. The first is the development of miniature neutron detectors that fit between the fuel channels of large power reactor cores thus making available detailed information about spacially dependent parameters. The second is the development of portable, high-speed Fourier Analyzers such as the HP 5451 with miniature computers for fast manipulation of the large amounts of data encountered in neutron noise analysis.

### **DESCRIPTION OF NUCLEAR POWER REACTORS**

The United States has relied almost exclusively on Light Water Reactors (LWR's) for nuclear production of electric power. There are two kinds of light water reactors presently in use: the most common is the Pressurized Water Reactor (PWR), in which high pressure water circulates through the reactor to a steam generator. In the steam generator, heat is transferred to water at a lower pressure to produce steam which drives the turbine-generator. The other type of reactor produces steam directly in the core and is called a Boiling Water Reactor (BWR). Figures 1 and 2¹ show some of the complexities of both reactor types.

Typically, power reactors are heavily instrumented with neutron detectors, having between thirty and four hundred in-vessel neutron detectors and ten or more exvessel neutron detectors. These neutron detectors are used to determine the level and distribution of power by detecting neutrons given off in the fission process. The current signal from the detector is directly proportional to the number of fissions, and so, the power level of the reactor. However, the current level contains only part of the information about the state of the reactor. As is summarized in the following argument <sup>2</sup>,<sup>3</sup>, we shall see that much more information is available through frequency analysis of neutron detector signals.

Neutrons enter the detector randomly due to their random movement and due to the noise-equivalent source with which they are created in the reactor. The neutron power spectral density (NPSD) observed in a reactor at power is given by

$$(1) \ \phi_{\mathsf{n}}(\omega) = \frac{2 \ \mathsf{W}_{\mathsf{n}} \ \mathsf{Q}^2 \ \mathsf{P}}{-\!\!\! \bigwedge} + \frac{\mathsf{W}_{\mathsf{n}}^2 \ \mathsf{Q}^2}{-\!\!\! \bigwedge^2} \ |\mathsf{G}_{\mathsf{O}}(\omega)|^2 \cdot \ [\phi_{\mathsf{S}}(\omega) + \mathsf{P}^2 \ \phi_{\rho}(\omega)]$$

where

 $\phi_{n}(\omega)$  = Neutron spectral power density

W<sub>n</sub> = The detector efficiency, equal to number of neutrons captured by the detector divided by the number of neutrons produced in the reactor




FIGURE 1. A Pressurized Water Reactor. Photo Courtesy of Westinghouse Electric Co. (Ref. 1)




FIGURE 2. A Boiling Water Reactor. Photo Courtesy of General Electric (Ref. 1)

Q = Charge transferred per neutron captured in the detector

P = The reactor power level

= The neutron generation time. Typically on the order of 10<sup>-5</sup> seconds, and usually available through the reactor physics information

 $G_{o}(\omega)$  = The zero power transfer function of the reactor. This is usually calculated, but can be measured experimentally. It is always a smoothly varying function

 $\phi_{s}(\omega)$  = The noise-equivalent neutron source

 $\phi_{
ho}(\omega)$  = The neutron noise caused by external perturbation such as core component vibrations and reactivity feedback effects At high power operation this can be approximated

(2) 
$$\phi_n(\omega) = \frac{P^2 W_n^2 Q^2}{-\Lambda^2} |G_0(\omega)|^2 [\phi_{\rho}(\omega)]$$

Since the average detector current I<sub>dc</sub>, an experimentally observed variable, is

$$I_{dc} = \frac{PW_n Q}{A}$$

Eq. (2) becomes

(4) 
$$\phi_{\text{n}}(\omega) \cong I_{\text{dc}}^2 |G_{\text{o}}(\omega)|^2 [\phi_{\rho}(\omega)]$$

The observed NPSD can then be normalized by dividing by  $I^2_{dC}$ . Theoretically predicting  $|G_O(\omega)|^2$  one can then obtain the actual magnitude of the driving function of external reactivity effects:

(5) 
$$\phi_{\rho}$$
 ( $\omega$ )  $\approx \frac{\phi_{n}(\omega)}{I_{cd}^{2}|G_{o}(\omega)|^{2}}$ 

The frequency spectrum of the NPSD measured in this manner does not resemble the zero-power measurements because  $\phi_{\rho}(\omega)$  does not have a white spectral density shape like the noise equivalent source which dominates at zero power.

This information makes neutron noise analysis useful for monitoring the integrity of in-core components. If a component becomes loose and vibrates due to the hydraulic forces of coolant flow, small reactivity fluctuations will result with attendant neutron noise.

Reactivity disturbances measured in this manner are extremely sensitive because of the amplifying effect of the term  $|G_0(\omega)|^2$  in the frequency range where many mechanical vibrations occur. Reactivity disturbances are subject to change with coolant flow rates, control rod positions, or fuel loading. Hence, to be certain of diagnoses from NPSD measurements, one must acquire a library of normal neutron noise patterns for normal operation. This effort is necessarily ongoing, and as malfunctions are detected, their "signatures" can be added to a collection of noise patterns from previously discovered problems.

#### 2.0 REACTOR CORE DIAGNOSTICS

#### 2.1 Detection of Core Component Vibration

While there are several examples 4,5,6 of loose or vibrating components in nuclear reactors, Fourier analysis has been available to characterize only a few of these. An example of the ability to make diagnoses of this condition by Fourier analysis techniques is the work<sup>2</sup> at the High Flux Isotope Reactor (HFIR).

Fig. 3 shows three sets of NPSD data taken at different times. The spectra before failure and after repair of an upper control guide bearing are similar. The spectrum taken while the bearing was broken shows a change in noise level, particularly at a frequency of 5 hz. The frequency is significant in that it is possibly the vibration characteristic of the control rod.




FIGURE 3. Change in HFIR Neutron-Fluctuation Spectrum as a Result of Rod Bearing Failure During an Early Fuel Cycle (Ref.2)

Several fuel cycles later, a different guide bearing failed with the result shown in Fig. 4. Note that the NPSD's are different for Figs. 3 and 4, and also that the increase in noise level was most pronounced at 5 hz. These results indicate the conclusion that it may be possible to detect bearing failures more quickly at HFIR with neutron noise monitoring than with any other instrumentation installed at that reactor.

The consequences of failure to detect and repair vibrating components in the core become more apparent with reactor operating experience. At the Muhleberg reactor in Switzerland, a poison curtain installed in the reactor for reactivity control, cracked loose and vibrated in the coolant flow. The vibration remained undiscovered until the pressure vessel was opened for refueling. The poison curtain had by that time damaged the surrounding fuel channels. The additional work of replacing the damaged fuel channels quite possibly increased the length of that reactor outage. Similar problems, now resolved by design changes, have been observed at the Vermont Yankee and the Pilgrim One reactors in this country.




FIGURE 4. Change in HFIR Neutron-Fluctuation Spectrum as a Result of Rod Bearing Failure During a Later Fuel Cycle (Ref. 2)

## 2.2 Detection of Core Motion

Core barrel motion has been detected on two occasions in modern PWR's. The first occured in 1969 at the Trino reactor in Italy.

This section describes the application of a Hewlett Packard (HP) Model 5451A Fourier Analyzer to diagnose core barrel motion in the second occurrence at the Palisades reactor in 1973.

The first indication of core barrel motion at Palisades came when operating personnel noticed low frequency oscillations in the power level indication of the ex-vessel detectors. Similar variations were not present in the in-vessel detector signals. Engineers were called in to perform measurements to determine if core motion was in fact present<sup>8</sup>. Their equipment included the Hewlett Packard Model 5451A Fourier Analyzer.

Fig. 5 shows the equipment used to perform the measurements. A more detailed description is available in Reference 8. The rolloff frequencies of the anti-aliasing filters were set at 0.4 times the Analog to Digital sampling rate.

Digitized Signals were Hanning-windowed using the Fast Fourier Analyzer. Data collection times were up to 2 hours to yield a standard deviation of not more than 2% on NPSD's. Cross-power spectral densities (CPSD's) were also computed between signals of different detectors.

The phase relationship between signals was computed from the measured data using

(6) 
$$\theta(f) = tan^{-1} \frac{IMCPSD}{RECPSD}$$

Where IMCPSD = Imaginary part of the CPSD RECPSD = Real part of the CPSD




FIGURE 5. Signal Conditioning and Analysis for Detection of Core Motion of Palisades (Ref. 8)

The other variable used as a diagnostic aid was coherence, which is a measure of the commonality of two signals (A and B). In this application it is computed as

(7) 
$$COH(f) = \gamma^2 = \frac{|CPSDAB(f)|^2}{PSDA(f) \cdot PSDB(f)}$$

Two perfectly correlated signals would have a coherence value of 1 and two completely unrelated noise signals would have a coherence value of 0.

The signals used in the measurements were taken from detectors whose locations are shown in Figure 6. Both in vessel and ex-vessel detectors were necessary to this analysis.




FIGURE 6. Neutron Detector Locations (Ref. 8)

Many tests were performed to assure signal quality. Fig. 7 shows the effect of an electrically noisy data logger on the signal. This source of extraneous noise would have contaminated all data had it not been detected and turned off during measurements. Hence, one of the real advantages of immediate data processing becomes apparent. It would have been very difficult to determine the cause of other peaks in the contaminated spectrum if frequency analysis had been performed offsite.




FIGURE 7. Effect of Data Logger on Detector Noise Signal (Ref. 8)

Fig. 8 shows the coherence and phase of the two ex-vessel detectors located diametrically opposite one another. Note the high coherence and the fact that the two signals are 180° out of phase.

Fig. 9 shows two NPSD's. The NPSD of the ex-vessel detector has a much higher content of low frequency noise that is not coherent with the in-vessel detector as shown in Fig. 10.

Upon opening the pressure vessel for inspection, significant wear was found on some restraining components, indicating that motion had indeed taken place.




FIGURE 8. Coherence and Phase Between Ex-core Detectors on Opposite Sides of the Vessel (Ref. 8)




FIGURE 9. Power Spectral Density of Ex-vessel and In-Core Detector Signals (Ref. 8)




FIGURE 12. Power Spectral Density Functions Measured in Lingen BWR Core (Ref. 11)

This code accepts use of portable survey instruments which measure only the displacement of vibration as valid. Unfortunately, much information about the possible deterioration of internal components is contained in changes that can be small with respect to the total amplitude but that are relatively large with respect to the vibration amplitude at a particular frequency. Hence, a frequency analysis of the vibration is a much more sensitive means of detecting incipient failure. Also, frequency analysis is useful as a diagnostic tool in the event that excessive vibration is found.

Trade literature indicates that detection of impending failure in rotating equipment is important because rotating equipment failures accounted for 65% of all forced outage in the first quarter of 1974<sup>13</sup>. The second greatest cause of forced outage (24%) was repairs to reactor components damaged by excessive vibration.

The HP Model 5451B Fast Fourier Analyzer with a rotating equipment package should find widespread usage in reducing the impact of these problems. The wide dynamic range (80dB) and high frequency response (up to 100 khz) make it possible to perform measurements with greater sensitivity and over a greater frequency range than with previously available instrumentation. The portability of HP analyzers makes application of turbine diagnostic procedures such as those developed in Europe<sup>14</sup> both practical and convenient.

The 5451B Fourier Analyzer extends the ability of machine problem analysts to gather complete vibration data during the normal startup of plant equipment with minimal interference in plant operation. Data such as that shown in Fig. 13 can be useful in diagnosing transient problems in the startup of a pump or turbine. The advantage that the Hewlett-Packard system offers over previous methods is the ability to collect and organize data at each motor speed during a single continuous pass from zero to full operating speed without stopping to establish constant speed, a requirement for traditional swept-frequency-type measurements.




FIGURE 13. RPM Spectral Map.

## 4.0 SEISMIC ANALYSIS OF NUCLEAR POWER PLANTS

Nuclear power plants are built to demanding seismic requirements<sup>15</sup> and are instrumented to confirm that the operating basis of the design is not exceeded in the event of an earthquake. Presently, the design and placement of instrumentation is primarily based on expensive calculated response spectra.

An alternative to the calculated placement of earthquake instrumentation is now available through measured response spectra based on impact tests and modal analysis available with the Model 5451B Fourier Analyzer. While this technique has been applied only to small-scale machinery<sup>16</sup> at this point, the potential of the application to nuclear power plants is clear.

An HP Fourier Analyzer is being employed for structural vibration measurements by the John A. Blume Earthquake Engineering Center at Stanford University, but to date these techniques have not been directly applied to nuclear power plant construction. Determination of structural integrity by remote, rather than visual inspection, is especially valuable because access to some areas of a nuclear power plant are limited after initial operation due to buildup of radioactivity.

## 5.0 PIPING ANALYSIS OF NUCLEAR POWER PLANTS

Another potential application is the modal analysis of vibrating pipes. Ideally, a piping designer would prefer to place pipe hangers and hydraulic snubbers (there are typically 8,000 - 10,000 in a nuclear power plant) at points of maximum vibration to reduce the possibility of fatigue failure or excessive wear of piping. The modal analysis package of the Model 5451B is well suited to this application. While it is unlikely that the piping designer could wait for measurements of this sort, the technique is useful for analysis of any problems that emerge from "as built" configurations, or in selecting hanger and snubber locations for piping which is modified after initial operation of the plant.

### 6.0 CONCLUSIONS

With proper application, the Hewlett Packard Model 5451B Fourier Analyzer offers the possible early detection of incipient failure. Early detection of problems can aid the reactor owner by increasing his plant reliability through knowledge of additional options in scheduling preventive maintenance, by finding alternate modes of operation, or in cessation of operation before more serious damage results.

Thus, the Fourier Analyzer contributes to the reliability of a nuclear power plant not only by measuring the operability of a given piece of hardware, but also by giving quantitative information about its status so that intelligent choices can be made with regard to the operation of the power plant system as a whole.

#### REFERENCES

- Directory of Nuclear Reactors, Vol. VII: Power Reactors, IAEA, Vienna, 1968. STI/PUB/174. Pages 55 and 191.
- 2. D. N. Fry, "Experience in Reactor Malfunction Diagnosis Using On-Line Noise Analysis," *Nuclear Technology*, Vol. 10, March 1971.
- J. C. Robinson, "Analysis of Neutron Fluctuation Spectra in the Oak Ridge Research Reactor and the High Flux Isotope Reactor," ORNL—4149, Oak Ridge National Laboratory (1967).
- GEAP—13979, F. H. Berg, et al. "State of the Art Report on Acoustical Monitoring of Nuclear Reactors," July 1973. Page 2-2.
- "Flow Induced Vibrations," USAEC Power Reactor Technology Vol. 8, pp. 273-275, Fall 1965.
- J. E. Reisland and E. A. Gustafson, "Work Performed on Fuel Channels and the Core Cupport Plate at Big Rock Point Nuclear Plant," ANS Transactions, Vol. 8 Supplement, 1965.
- 7. Nucleonics Week, November 22, 1973, p.6.
- 8. D. N. Fry, R. C. Kryter, and J. C. Robinson, "On-Site Noise Diagnostics at Palisades Nuclear Power Station." A paper presented to the Symposium on Power Plant Dynamics, Control and Testing held Oct. 8-10, 1973 at Knoxville, Tennessee, and sponsored by the Power Plant Dynamics, Control and Testing Division of the University of Tennessee Engineering Experiment Station, The American Nuclear Society and the Instrument Sciety of America.
- ROE 74-3 Reactor Safety-Operating Experiences, USAEC, "Mechanical Vibrations of Reactor Internals" Feb. 8, 1974.
- W. M. Rohsenhow and H.Y. Choi, "Heat Mass and Momentum Transfer," Prentice Hall, Inc., Englewood Cliffs, N.J. 1961, p.212.
- D. Stegemann, P. Gebureck, A. T. Mikulski and W. Seifritz, "Operating Characteristics of a Boiling Water Reactor Deduced from In-Core Measurements." A paper presented at the same symposium as Reference 8.
- 12. ASME Boiler and Pressure Vessel Code, Section XI, Subsection IWP, "Inservice Testing of Pumps in Nuclear Power Plants." Summer 1973, Addenda.
- "Factors Responsible for Delay in Getting Nuclear Power On Line," Nuclear Industry Magazine, April 1974, pages 22 and 23.
- "On-Load Surveillance of Nuclear Power Plant Components by Noise and Vibration Analysis," Status Report on work performed for the Commission of the European Communities under Euratom Study Contract No. 043-71-10 ECIC (F), April, 1972.
- 15. U.S.A.E.C. Regulatory Guide 1.12, "Instrumentation for Earthquakes."
- I. E. Morse, W. R. Shapton, D. L. Brown and G. Kuljanic, "Application of Pulse Testing for Determining Dynamic Characteristics of Machine Tools." HP Application Note 140-3.

## HEWLETT · PACKARD

# ELECTRONIC INSTRUMENTATION SALES AND SERVICE

UNITED STATES, CENTRAL AND SOUTH AMERICA, CANADA

#### UNITED STATES

ALABAMA 8290 Whitesburg Dr., S.E. P.O. Box 4207 Hunstville 35802 Tel: (205) 881-4591 TWX: 810-726-2204

ARIZONA ARIZONA 2336 E. Magnolia St. Phoenix 85034 Tel: (602) 244-1361 TWX: 910-951-1330

2424 East Aragon Rd. Tucson 85706 Tel: (602) 889-4661

CALIFORNIA 1430 East Orangethorpe Ave. Fullerton 92631 Tel: (714) 870-1000 TWX: 910-592-1288

3939 Lankershim Boulevard North Hollywood 91604 Tel: (213) 877-1282 TWX: 910-499-2170

6515 Arizona Piace Los Angeles 90045 Tel: (213) 776-7500 TWX: 910-328-6148

1101 Embarcadero Road Palo Alto 94303 Tel: (415) 327-6500 TWX: 910-373-1280

2220 Watt Ave. Sacramento 95825 Tel: (916) 482-1463 TWX: 910-367-2092

9606 Aero Drive P.O. Box 23333 San Diego 92123 Tel: (714) 279-3200 TWX: 910-335-2000

COLORADO 5600 South Ulster Parkway Englewood 80110 Tel: (303) 771-3455 IWX: 910-935-0705

CONNECTICUT New Haven 06525 Tel: (203) 389-6551 TWX: 710-465-2029

FLORIDA FLORIDA P 0, Box 24210 2806 W, Oakland Park Blvd. Ft. Lauderdale 33307 Tel: (305) 731-2020 TWX: 510-955-4099

P.O. Box 13910 6177 Lake Ellenor Dr. Orlando, 32809 Tel: (305) 859-2900 TWX: 810-850-0113

GEORGIA P.O. Box 28234 450 Interstate North Atlanta 30328 Tel: (404) 436-6181 TWX: 810-766-4890

HAWAII 2875 So. King Street Honolulu 95814 Tel: (808) 955-4455

ILLINOIS ward Street 5500 Howard Street Skokle 60076 Tel: (312) 677-0400 TWX: 910-223-3613

INDIANA 3839 Meadows Drive Indianapolis 46205 Tel: (317) 546-4891 TWX: 810-341-3263

IOWA 1902 Broadway lowa City 52240 Tel: (319) 338-9466 Night: (319) 338-9467

LOUISIANA
P. 0. Box 840
3239 Williams Boulevard
Kenner 70062
Tel: (504) 721-6201
TWX: 810-955-5524

MARYLAND 6707 Whitesto stone Road Baltimore 21207 Tel: (301) 944-5400 TWX: 710-862-9157

20010 Century Blvd. Germantown 20767 Tel: (31) 428-0700

P.O. Box 1648 2 Choke Cherry Road 2 Choke Cherry Roa Rockville 20850 Tel: (301) 948-6370 TWX: 710-828-9684

MASSACHUSETTS 32 Hartwell Ave. Lexington 02173 Tel: (617) 861-8960 TWX: 710-326-6904

MICHIGAN

MINNESOTA 2459 University Aven St. Paul 55114 Tel: (612) 645-9461 TWX: 910-563-3734 ty Avenue

MISSOURI 11131 Colorado Ave. Kansas City 64137 Tel: (816) 763-8000 TWX: 910-771-2087

148 Weldon Parkway Maryland Heights 63043 Tel: (314) 567-1455 TWX: 910-764-0830

\*NEVADA Las Vegas Tel: (702) 382-5777

NEW JERSEY W. 120 Century Rd. Paramus 07652 Tel: (201) 265-5000 TWX: 710-990-4951

NEW MEXICO P.O. Box 8366 Station C 6501 Lomas Boulevard N.E. Albuquerque 87108 Tel: (505) 265-3713 TWX: 910-989-1665

156 Wyatt Drive Las Cruces 88001 Tel: (505) 526-2485 TWX: 910-983-0550

NEW YORK 6 Automation Lane Computer Park Albany 12205 Tel: (518) 458-1550 TWX: 710-441-8270

1219 Campville Road Endicott 13760

New York City Manhattan, Bronx Contact Paramus, NJ Office Tel: (201) 265-5000 Brooklyn, Queens, Richmond Contact Woodbury, NY Office Tel: (516) 921-0300

82 Washington Street Poughkeepsle 12601 Tel: (914) 454-7330 TWX: 510-248-0012

39 Saginaw Drive Rochester 14623 Tel: (716) 473-9500 TWX: 510-253-5981 5858 East Molloy Road Syracuse 13211 Tel: (315) 454-2486 TWX: 710-541-0482

1 Crossways Park West Woodbury 11797 Tel: (516) 921-0300 TWX: 510-221-2168

NORTH CAROLINA P.O. Box 5188 1923 North Main Street 1923 North Main Str High Point 27262 Tel: (919) 885-8101 TWX: 510-926-1516

SOUTH CAROLINA

OHIO 16500 Sprague Road Cleveland 44130 Tel: (216) 243-7300 Night: 243-7305 TWX: 810-423-9431

330 Progress Rd. Dayton 45449 Tel: (513) 859-8202 TWX: 810-459-1925 6665 Busch Blvd. Columbus 43229 Tel: (614) 846-1300

OKLAHOMA P.O. Box 32008 Oklahoma City 73132 Tel: (405) 721-0200 TWX: 910-830-6862

OREGON 17890 SW Boones Ferry Road Tualatin 97062

PENNSYLVANIA 111 Zeta Drive Pittsburgh 15238 Tel: (412) 782-0400 Night: 782-0401 TWX: 710-795-3124

1021 8th Avenue King of Prussia Industrial Park King of Prussia 19406 Tel: (215) 265-7000 TWX: 510-660-2670

RHODE ISLAND 873 Waterman Ave. East Providence 02914 Tel: (401) 434-5535 TWX: 710-381-7573

\*TENNESSEE Memphis Tel: (901) 274-7472 TEXAS Richardson 75080 Tel: (214) 231-6101 TWX: 910-867-4723 P.O. Box 27409 6300 Westpark Drive Suite 100 Houston 77027 Tel: (713) 781-6000 TWX: 910-881-2645 231 Billy Mitchell Road San Antonio 78226

Tel: (512) 434-4171 TWX: 910-871-1170 UTAH 2890 South Main Street Salt Lake City 84115 Tel: (801) 487-0715 TWX: 910-925-5681

VIRGINIA
P.O. Box 9854
2914 Hungary Springs Road
Richmond 23228
Tel: (804) 285-3431
TWX: 710-956-0157

WASHINGTON Bellefid Office Pk. 1203 - 114th SE Bellevue 98004 Tel: (206) 454-3971 TWX: 910-443-2446

\*WEST VIRGINIA Charleston Tel: (304) 345-1640 WISCONSIN 9431 W. Befoit Road Suite 117 Milwaukee 53227 Tel: (414) 541-0550

FOR U.S. AREAS NOT LISTED: Contact the regional office near-est you: Atlanta, Georgia... North Hollywood, California. Paramus, New Jersey .. Skokie, Illinois. Their complete ad-dresses are listed above. \*Service Only

## CENTRAL AND SOUTH AMERICA

ARGENTINA ARGENTINA Hewlett-Packard Argentina S.A.C.e.I Lavaile 1171 - 3° Buenos Aires Tel: 35-0436, 35-0627, 35-0341 Telex: 012-11009 Cable: HEWPACK ARG

BOLIVIA Stambuk & Mark (Bolivia) LTDA. Av. Mariscal, Santa Cruz 1342 La Paz Tel: 40626, 53163, 52421 Telex: 3560014 Cable: BUKMAR

BRAZIL Hewlett-Packard Do Brasil Hewlett-Packard Do Brasil I.E.C. Ltds. Rua Frei Caneca 1119 01307-Sao Paulo-SP Tel: 288-7111, 287-5858 Telex: 309151/2/3 Cable: HEWPACK Sao Paulo

Hewlett-Packard Do Brasil Hewlett-Packard Do Brasil I.E.C. Ltda, Praca Dom Fellclano, 78 90000-Porto Alegre-RS Rio Grande do Sul (RS) Brasil Tel: 25-8470 Cable: HEWPACK Porto Alegre

Hewlett-Packard Do Brasil Hewett-Packard Do Brasil I.E.C. Lida. Rua da Matriz, 29 20000-Río de Janeiro-GB Tel: 266-2643 Telex: 210079 HEWPACK Cable: HEWPACK Río de Janeiro

CHILE Calcagni y Cia, Ltda. Casilla 16.475 Santiage Tel: 423 96 Cable: CALCAGNI Santiago

COLOMBIA Instrumentación
Henrik A. Langebaek & Kier S.A.
Carreta 7 No. 48-59
Apartado Aéreo 6287
Bogota, 1 D.E.
Tel: 45-78-06, 45-5-46
Cable: AARIS Bogota
Telex: 44400INSTCO

COSTA RICA Lic. Alfredo Gallegos Gurdián Apartado 10159 Apartado 10155 San José Tel: 21-86-13 Cable: GALGUR San José

**ECUADOR** Laboratorios de Radio-Ingenieria Calle Guayaquil 1246 Post Office Box 3199 Quito Tel: 212-496; 219-185 Cable: HORVATH Quito

EL SALVADOR
Electronic Associates
Apartado Postal 1682
Centro Comercial Gigante
San Salvador, El Salvador C.A.
Paseo Escalon 4649-4" Piso
Tel: 23-44-60, 23-32-37
Cable: ELECAS

GUATEMALA IPESA IPESA Avenida La Reforma 3-48, Zona 9 Guatemala Tel: 63627, 64736 Telex: 4192 TELTRO GU

MEXICO MEXICO Hewlett-Packard Mexicana, S.A. de C.V. Torres Adalid No. 21, 11° Piso Col. del Valle Mexico 12, D.F. Tel: 543-42-32 Telex: 017-74-507

NICARAGUA

Roberto Terán G. Apartado Postal 689 Edificio Terán Edificio Terán Managua Tel: 3451, 3452 Cable: ROTERAN Managua PANAMA Electrónico Balboa, S.A. P.O. Box 4929 Ave. Manuel Espinosa No. 13-50

Ave. Manuel Espinosa No. 13-50 Bidg. Alina Panama City Tel: 230833 Telex: 3481103, Curunda, Canal Zone Cable: ELECTRON Panama City

PARAGUAY Z. J. Melamed S.R.L. Division: Aparatos y Equipos Medicos Medicos
Division: Aparatos y Equipos
Scientificos y de
Investigacion
P.O. Box 676 Chile, 482, Edificio Victoria Asuncion Tel: 4-5069, 4-6272 Cable: RAMEL

PERU PERU Compañía Electro Médica S.A. Ave. Enrique Canaual 312 San Isldro Casilla 1030 Lima Tel: 22-3900 Cable: ELMED Lima

PUERTO RICO San Juan Electronics, Inc. P.O. Box 5167 Ponce de Leon 154 Pda. 3-PTA de Tierra San Juan 00906 Tel: (809) 725-3342, 722-3342 Cable: SATRONICS San Juan Telex: SATRON 3450 332 URUGUAY
Pablo Ferrando S.A.
Comercial e Industrial
Avenida Halia 2877
Casilla de Correo 370
Montevideo
Tel: 40-3102
Cable: RADIUM Montevideo

VENEZUELA Hewlett-Packard de Venezuela Hewlett-Packard de Vene C.A. Apartado 50933 Edificio Segre Tercera Transversal Los Ruices Norte Caracas 107 Tel: 35-00-11 Telex: 21146 HEWPACK Cable: HEWPACK Caraca

FOR AREAS NOT LISTED, CONTACT: CONTACT: Hewlett-Packard Inter-Americas 3200 Hillview Ave. Pale Atto, California 94304 Tel: (415) 493-1501 TWX: 910-373-1267 Cable: HEWPACK Palo Alto Telex: 034-8300, 034-8493

#### CANADA

ALBERTA Hewlett-Packard (Canada) Ltd. 11748 Kingsway Ave. Edmonton TSG 0X5 Tel: (403) 452-3670 TWX: 610-831-2431

Hewlett-Packard (Canada) Ltd. 915-42 Avenue S.E. Calgary 126 121 Tel: (403) 262-4279

BRITISH COLUMBIA Hewlett-Packard (Canada) Ltd. 837 E. Cordova Street Vancouver V6A 3R2 Tel: (604) 254-0531 TWX: 610-922-5059

MANITOBA Hewlett-Packard (Canada) Ltd. 513 Century St. St. James Winnipeg R3H 0L8 Tel: (204) 786-7581 TWX: 610-671-3531

NOVA SCOTIA Hewlett-Packard (Canada) Ltd. 2745 Outch Village Rd. Halifax B3L 4G7 Tel: (902) 455-0511 TWX: 610-271-4482

ONTARIO Hewiett-Packard (Canada) Ltd. 1785 Woodward Dr. Ottawa K2C 0P9 Tel: (613) 225-6530 TWX: 610-562-8968

Hewlett-Packard (Canada) Ltd. 6877 Goreway Drive Mississauga L4V 1L9 Tel: (416) 678-9430 TWX: 610-492-4246

QUEBEC Hewlett-Packard (Canada) Ltd. 275 Hymus Boulevard Pointe Claire H9R 1G7 Tel: (518) 551-5520 TWX 610-422-3022 Telex: 05-821521 HPCL Hewlett-Packard (Canada) Ltd. 2376 Galvani Street Ste-Foy GIN 4G4 Tel: (418) 688-8710

FOR CANADIAN AREAS NOT LISTED: Contact Hewlett-Packard (Can-ada) Ltd. in Mississauga

## HEWLETT · PACKARD

# ELECTRONIC INSTRUMENTATION SALES AND SERVICE

# EUROPE, AFRICA, ASIA, AUSTRALIA **EUROPE**

AUSTRIA Hewlett-Packard Ges.m.b.H Handelska 52/3

P.O. Box 7
A-1205 Vienna
Tel: (0222) 33 66 06 to 09
Cable: HEWPAK Vienna
Telex: 75923 hewpak a

BELGIUM Hewlett-Packard Benelux S.A./N.V. Avenue de Col-Vert. 1

DENMARK Vawlett-Packard A/S Hewlett-Packard A/S Datavej 38 DK-3460 Birkerod Tel: (01) 81 66 40 Cable: HEWPACK AS Telex: 166 40 hp as

Hewlett-Packard A/S Torvet 9 DK-8500 Silkeborg Tel: (06) 82-71-66 Telex: 166 40 hp as Cable: HEWPACK AS

FINLAND
Hewlett-Packard Oy
Bulevardi 26
P.O. Box 12185
SF-00120 Helsinki 12
Tel: (90) 13730
Cable: HEWPACKOY Helsinki
Telex: 12-15363 hel

FRANCE Hewlett-Packard France Quartier de Courtaboeuf Borte Postale No. 6 F-91401 Orsay Tel: (1) 907 78 25 Cable: HEWPACK Orsay Telex: 60048

Hewlett-Packard France Hewlett-Packard France Agenee Regional 4 Qual des Etroits F-69321 Lyon Cedex 1 Tel: (78) 42 63 45 Cable: HEWPACK Lyon Telex: 31617

Hewlett-Packard France Zone Aéronautique Avenue Clement Ader F-31770 Colomiers Tel: (61) 86 81 55 Telex: 51957

Hewlett-Packard France F-13100 Luynes Tel: (47) 24 00 66 Telex: 41770

Hewlett-Packard France Agency Régionale 63, Avenue de Rochester F-35000 Rennes Tel: (99) 36 33 21 Telex: 74912 F

Hewlett-Packard France Agence Régionale
74, Allée de la Robertsau
F-67000 Strasbourg
Tel: (88) 35 23 20/21
Telex: 89141
Cable: HEWPACK STRBG

GERMAN FEDERAL GERMAN FEDERAL REPUBLIC Hewlett-Packard GmbH Vertriebzentrale Frankfurt Bernerstrasse 117 Postfach 550 140 D-6000 Frankfurt 56 Tel: (0611) 50 04-1 Cable: HEWPACKSA Frankfurt Telex: 41 32 49 fra

Hewist 41 32 49 fra
Hewlett-Packard GmbH
Vertriebsbüro Böblingen
Herrenbergerstrasse 110
D-7030 Böblingen, Württe
Tel: (07031) 65 72 87
Cable: HEPAK Böblingen
Telex: 72 65 739 bbn

Hewlett-Packard GmbH Vertriebsbüro Düsseldorf Vogelsanger Weg 38 D-4000 Düsseldorf Tel: (0211) 63 80 31/38 Telex: 85/86 533 hpdd d

Hewlett-Packard GmbH Vertriebsbüro Hamburg Wendenstr. 23 D-2000 Hamburg 1 Tel: (040) 24 13 93 Cable: HEWPACKSA Hamburg Telex: 21 63 032 hphh d

Hewlett-Packard GmbH Vertriebsbüro Hannover Mellandorfer Strasse 3 D-3000 Hannover-Kleefeld Tel: (0511) 55 06 26

Hewlett-Packard GmbH Vertriebsburo Nuremberg Hersbruckerstrasse 42 D-8500 Nuremberg Tel: (0911) 57 10 66 Telex: 623 860

Hewlett-Packard GmbH Vertriebsbüro München Unterhachinger Strasse 28 ISAR Center D-8012 Ottobrunn Tel: (089) 601 30 61/7 Telex: 52 49 85 Cable: HEWPACKSA Müchen

(West Berlin)
Hewlett-Packard GmbH
Vertriebsbüro Berlin
Wilmersdorfer Strasse 113/114
D-1000 Berlin W. 12
Tel: (030) 137046
Telex: 18 34 05 hpbin d

GREECE Rostas Karayannis 18, Ermou Street GR-Athens 126 Tel: 8080337, 8080359, 8080429, 8018693 Cable: RAKAR Athens Telex: 21 59 62 rkar gr

Hewlett-Packard S.A. Mediterranean & Middle East Operations
35 Kolokotroni Street
Platia Kefallarion Gr-Kifissia-Athens Tel: 8080337, 8080358, 8080429, 8018693

IRELAND Hewlett-Packard Ltd. 224 Bath Road GB-Slough, SL1 4 DS, Bucks Tel: Slough (0753) 33341 Cable: HEWPIE Slough Telex: 848413

Hewlett-Packard Ltd. The Graftons The Graftons Stamford New Road Altrincham, Cheshire Tel: (061) 928-9021 Telex: 668068

ITALY Hewlett-Packard Italiana S.p.A. Via Amerigo Vespucci 2 I-20124 Milan Tel: (2) 6251 (10 lines) Cable: HEWPACKIT Milan Telex: 32046 Hewlett-Packard Italiana S.p.A.

Vicolo Pastori, 3 I-35100 Padova Tel: (49) 66 40 62 Telex: 32046 via Milan Hewlett-Packard Italiana SPA Via Medaglie d'Oro, 2 1-55100 Pisa Tel: (050) 500022

Hewlett-Packard Italiana S.p.A. Via Colli, 24 I-10129 Turin Tel: (11) 53 82 64 Telex: 32046 via Milan

LUXEMBURG Hewlett-Packard Benelux S.A./N.V. Avenue de Col-Vert, 1, (Groenkraaglaan) 8-1170 Brussels Tel: (03/02) 72 22 40 Cable: PALOBEN Brussels Telex: 23 494

NETHERLANDS Hewlett-Packard Benelux/N.V. Hewlett-Packard Benelux/N.V Weerdestein 117 P.O. Box 7825 NL-Amsterdam, 1011 Tel: 5411522 Cable: PALOBEN Amsterdam Telex: 13 216 hepa ni

NORWAY

Normal Norge A/S Hewlett-Packard Norge Nesveien 13 Box 149 N-1344 Hastum Tel: (02) 53 83 60 Telex: 16621 hpnas n

PORTUGAL
Telectra-Empresa Técnica de
Equipamentos Eléctricos S.a.r.I.
Rua Rodrigo da Fonseca 103
P.O. Box 2531
P-Lisbon 1 Tel: (19) 68 60 72 Cable: TELECTRA Lisbon Telex: 1598

SPAIN Hewlett-Packard Española, S.A. Jerez No 8 E-Madrid 16 Tel: 458 26 00 Telex: 23515 hpe

Telex: 23515 hpe Hewlett-Packard Española, S.A. Milanesado 21:23 E-Barcelona 17 Teli: (3) 203 62 00 Telex: 52603 hpbe e Telewlett-Packard Espanola S.A. Av Ramon y Cajal, 1 Edificio Sevilla I, planta \*9 E-Seville

SWEDEN

SWEDEN
Hewlett-Packard Sverige AB
Enighetsvägen 1-3
Fack
5-161 20 Bromma 20
Tel: (08) 730 0550
Cable: MEASUREMENTS
Stockholm
Telex: 10721

Hewlett-Packard Sverige AB Hagakersgatan 9C S-431 41 Mölndal Tel: (031) 27 68 00/01 Telex: Via Bromma

SWITZERLAND
Hewlett Packard (Schweiz) AG
Zürcherstrasse 20
70. 8ox 64
CH-8952 Schlieren Zurich
Tel: (01) 98 18 21/24
Cable: HPAG CH
Telex: 53933 hpag ch Hewlett-Packard (Schweiz) AG 9, Chemin Louis-Pictet CH-1214 Vernier—Geneva Tel: (022) 41 4950 Cable: HEWPACKSA Geneva Telex: 27 333 hpsa ch TURKEY
Telekom Engineering Bureau
Saglik Sok No. 15/1
Ayaspasa-Beyoglu
P.O. Box 437 Beyoglu
TR-Istanbul
Tel: 49 40 40
Cable: TELEMATION Istanbul

UNITED KINGDOM UNITED KINGDOM Hewlett-Packard Ltd. 224 Bath Road GB-Slough, SL1 4 DS, Bucks Tel: Slough (0753) 33341 Cable: HEWPIE Slough Telex: 848413

Hewlett-Packard Ltd. "The Graftons" Stamford New Road GB-Altrincham, Cheshire Tel: (061) 928-9021 Telex: 668068

Hewlett-Packard, Ltd.
c/o Makro
South Service Wholesale Centre
Amber Way
Halesowen Industrial Estate
GB-Wercs,
Tel: Birmingham 7860

Hewlett-Packard Ltd's registered address for V.A.T., purposés address for some only: 70, Finsbury Pavement London, EC2AISX Registered No: 690597

SOCIALIST COUNTRIES PLEASE CONTACT: PLEASE CONTACT: Hewlett-Packard Ges.m.b.H. Handelskal 52/3 P.O. Box 7 A-1205 Vienna Ph: (0222) 33 58 06 to 09 Cable: HEWPACK Vienna Telex: 75923 hewpak a

Telex: 75923 htmpsk s
ALL OTHER EUROPEAN
COUNTRIES CONTACT:
Hewlett-Packard S.A.
Rue du Bois-do-Lan 7
P.O. Box 85
CH-1217 Meyrin 2 Geneva
Switzerland
Tel: (022) 41 54 00
Cable: HEWPACKSA Geneva
Telex: 2 24 88

# AFRICA, ASIA, AUSTRALIA

ANGOLA
Telectra-Empresa Tecnica
de Equipamentos Electricos
SARL
Rua de Barbosa, Rodrígues,
42-1", 01"
P.O. Box 6487
Luanda
Cable: TELECTRA Luanda

AUSTRALIA Hewlett- Packard Australia Hewiett Packard Australia Pty. Ltd., 31-51 Joseph Street Victoria, 3130 Tel: 89 6351 Cable: HEWPARD Melbourne Telex: 31 024

Hewlett-Packard Australia Hewlett-Packard Australia
Pty. Ltd.
31 Bridge Street
Pymble,
New South Wales, 2073
Tel: 449 6556
Telex: 21561
Cable: HEWPARD Sydney

Hewlett-Packard Australia Pty. Ltd. 97 Churchill Road Prospect 5082 South Australia Tel: 44 8151 Cable: HEWPARD Adelaide

Hewlett-Packard Australia Pty. Ltd. Casablanca Buildings 196 Adelaide Terrace Perth, WA. 6000 Tel: 25-6800 Cable: HEWPARD Perth Hewlett-Packard Australia Pty. Ltd.

Pty. Ltd. 10 Woolley Street P.O. Box 191 Dickson A.C.T. 2502 Tel: 49-8194 Cable: HEWPARD Canberra ACT Hewlett-Packard Australia Pty. Ltd. 2nd Floor, 49 Gregory Terrace Brisbane, Queensland, 4000 Tel: 29 1544

CEYLON United Electricals Ltd. P.O. Box 681 50, Park St. Colombo 2 Tel: 26696 Cable: HOTPOINT Colombo

CYPRUS Kypronics 19 Gregorios & Xenopoulos Road P.O. Box 1152 CY-Nicosia Tel: 45628/29 Cable: KYPRONICS PANDEHIS

ETHIOPIA African Salespower & Agency Private Ltd., Co. P. O. Box 718 58/59 Cunningham St. Addis Ababa Tel: 12285 Cable: ASACO Addisababa

Cable: ASACO AddIsababa
HONG KONG
Schmidt & Co. (Hong Kong) Ltd.
P.O. Box 297
Connalight Centre
Connalight Centre
Connalight Road, Central
Hong Kong
Tel: 240168, 232735
Telex: MAZGG
Cable: SCHMIDTCO Hong Kong
Cable: SCHMIDTCO Hong Kong

INDIA
Bilue Star Ltd.
Kasturi Buildings
Jamshedji Tata Rd.
Bombay 400 020
Tel: 29 50 21
Telex: 3751
Cable: BLUEFROST

Blue Star Ltd. 5anas 414/2 Vir Savarkar Marg Prabhadevi Bombay 400 025 Tel: 45 78 87 Telex: 4093 Cable: FROSTBLUE

Blue Star Ltd.
Band Box House
Prabhadevi
Bombay 400 025
Tel: 45 73 01
Telex: 3751
Cable: BLUESTAR Blue Star Ltd. 14/40 Civil Lines Kampur 208 001 Tel: 6 88 82 Cable: BLUESTAR

Blue Star, Ltd. 7 Hare Street P.O. Box 506 P.O. Box 506 Calcutta 700 001 Tel: 23-0131 Telex: 655 Cable: BLUESTAR Blue Star Ltd.
Blue Star House,
34 Ring Road
Lajpat Nagar
New Delhi 110 024
Tel: 62 32 76
Telov. 2463

Telex: 2463 Cable: BLUESTAR Blue Star, Ltd. Blue Star House 11/11A Magarath Road Bangalore 560 025 Telex: 430 Cable: BLUESTAR Blue Star, Ltd. 1-1-117/1 Sarojini Devi Road Secunderabad 500 00 Tel: 7 63 91, 7 73 93 Cable: BLUEFROST Telex: 459

Blue Star, Ltd. 23/24 Second Line Beach Madras 600 001 Tel: 23954 Telex: 379 Cable: BLUESTAR

Cable: BLUESTAR
Blue Star, Ltd.
Nathraj Mansions
2nd Floor Bistupur
Jamshedpur 831 001
Tel: 38 04
Cable: BLUESTAR
Telex: 240

INDONESIA Bah Bolon Trading Coy. N.V. Dialah Merdeka 29 Randung Bandung Tel: 4915; 61560 Cable: ILMU Telex: 08-809

IRAN
Multi Corp International Ltd.
Avenue Soraya 130
P.O. Box 1212
IR-Teheran
Teler: 33 10 35-39
Cable: MULTICORP Tehran
Teler: 2893 MCI TN

ISRAEL
Electronics & Engineering
Div. of Motorola Israel Ltd.
17 Aminadav Street
Tel-Aviv
Tel-36941 (3 lines)
Cable: BASTEL Tel-Aviv
Telsz: 33569

JAPAN
Yokogawa-Hewlett-Packard Ltd.
Ohashi Building
1-59-1 Yoyogi
Shibuya-ku, Takya
Tel: 03-370-2281/92
Telex: 232-2024YHP
Cable: YHPMARKET TOK 23-724

Cable: THYMAKKET TOK 23-724
Yokogawa-Hewlett-Packard Ltd.
Nisel Ibaragi Bldg.
2-2-8 Kasuga
Ibaragi-Sh
Osaka
Tel: (0726) 23-1641
Telex: 5332-385 YHP OSAKA Yokogawa-Hewlett-Packard Ltd. Nakamo Buildina-cho No. 24 Kamisasazima-cho Nakamura-ku, Nagoya City Tel: (052) 571-5171

Yokogawa-Hewlett-Packard Ltd. Nitto Bldg. 2-4-2 Shinohara-Kita

Yokogawa-Hewlett-Packard Ltd. Chuo Bidg. Rm. 603 3, 2-C-home 1ZUM1-CHO, Mito, 310 Tel: 0292-25-7470

KENYA Kenya Kinetics P.O. Box 18311 Nairobi, Kenya Tel: 57726 Cable: PROTON

KOREA American Trading Company American Trading Company Korea, I.P.O. Box 1103 Dae Kyung Bldg., 8th Floor 107 Sejong-Ro, Chongro-Ku, Sepul Tel: (4 lines) 78-8924-7 Cable: AMTRACO Seoul

LEBANON
Constantin E. Macridis
P.O. Box 7213
RL-Beirut
Tel: 220846
Cable: ELECTRONUCLEAR Beirut

MALAYSIA MALAYSIA MECOMB Malaysia Ltd. 2 Lorong 13/EA Section 13 Petaling Jaya, Selanger Cable: MECOMB Kusia Lumpu

MOZAMBIQUE A.N. Goncalves, Lta. 162, Av. D. Luis P.O. Box 107 Losrenco Marques fel: 27091, 27114 Teles: 5-203 Negon Mo Cable: NEGON

NEW ZEALAND Hewlett-Packard (N.Z.) Ltd. 94-96 Dixon Street P.O. Box 9443 Courtenay Place, Wellington Tel: 59-559 Telex: 3898 Cable: HEWPACK Wellington Hewlett-Packard (N.Z.) Ltd.
Pakuranga Professional Centre
267 Pakuranga Highway
Box 51092
Pakuranga
Tel: 559-651
Cable: HEWPACK, Auckland

NIGERIA
The Electronics Instrumentations Ltd. (TELI)
144 Agege Motor Rd., Mushin
P.O. Box 6645
Lages
Cable: THETEIL Lagos

The Electronics Instrumenta-tions Ltd. (TEIL) 16th Floor Cocoa House P.M.B. 5402 Ibadan Tel: 23325 Cable: THETEIL Ibadan

PAKISTAN
Mushko & Company, Ltd.
Oosman Chambers
Abdullah Haroon Road
Karachi 3
Tel: 511027, 512927
Gable: COOPERATOR Karachi

Mushko & Company, Ltd. 388, Satellite Town Rawalpindi 388, Satellite Town Rawalpindi Tel: 41924 Cable: FEMUS Rawalpindi

PHILIPPINES
Electromex, Inc.
6th Floor, Amalgamahed
Development Corp., Bidg.
Ayala Annual, Makati, Rizal
C.C.P.O. Ber 1002
Makati, Nizal
Feli Be-13-47, 87-79-72,
Cable: ELEMEX Manila

Casine ELEMEX Manils
SINGAPORE
Mechanical & Combustion
Engineering Company Pts.,
Ltd.
10/12, Jalan Kilang
Red Rill Industrial Estate
Singapore, 3
Tal. 647151 (7 lines)
Cable: MECOMB Singapore

Hewlett-Packard Far East Memiett-Packard Far East Area Office P.O. Box 87 Alexandra Post Office Singapers 3 Tel: 633022 Cable: HEWPACK SINGAPORE

SOUTH AFRICA Hewlett Packard South Africa (Pty.), Ltd. Hewlett-Packard House Daphne Street, Wendywood, Sandton, Transvaal 2001 Tel: 407641 (five lines)

Hewlett Packard South Africa Hewlett Packard South Africa (Pty.), Ltd. Breecastle House Bree Street Cape Town Tel: 2-6941/2/3 Cable: HEWPACK Cape Town Telex: 0006 CT

Hewlett Packard South Africa (Pty.), Ltd. 641 Ridge Road, Durban P.O. Box 99 Overport, Natal Tel: 88-6102 Telex: 567954 Cable: HEWPACK

TAIWAN

TAIWAN
Herelett Packard Taiwan
30 Chung Shina West Road
50c. 1
50c. 1
Corresponding Training
Corp. Bidg. 7th Floor
Taipel
Tel: 389160,1,2, 375121,
Est. 240-249
Telex: TP924 HEWPACK
Cable: HEWPACK Taipel

THAILAND UNINESA Co., Ltd. Chargkoines Building 55 Sprivangse Road Roanke 56 Suriwongse Road Bangkak Teli 37956, 31300, 31307, 37540 Cable: UNIMESA Bangkok

UGANDA UGANDA Uganda Tele-Electric Co., Ltd. P.O. Box 4449 Kampala Tel: 57279 Cable: COMCO Kampala

VIETNAM
Paninular Trading Inc.
P.O. See H-3
216 Hien-Yuong
Salgan
Tel: 20-805, 93398
Cable: PENTRA, SAIGON 242

ZAMBIA R. J. Tilbury (Zambia) Ltd. P.O. Box 2792 Lusaka Zambia, Central Africa Tel: 73793 Cable: ARJAYTEE, Lusaka

MEDITERRANEAN AND MIDDLE EAST COUNTRIES NOT SHOWN PLEASE CONTACT: Hewiett-Packard S.A.
Mediterranean and Middle
East Operations
35, Kolokotroni Street—
Platia Kefaliariou
GR-Kifissla—Athens
Cable: HEWPACKSA Athens
Telex: 21-5588

OTHER AREAS NOT LISTED, CONTACT: Hewlett-Packard Export Trade Company 3200 Hillview Ave. Palo Alto, California 94304 Tel: (415) 493-1501 TWX: 910-373-1267 Cable: HEWPACK Palo Alto Telex: 034-8300, 034-8493



Printed in U.S.A.