S E R V I C E N O T E

SUPERSEDES: None

54520C Oscilloscope

Serial Numbers: US0000000/US99999999

Test Failure: Display shuts down after instrument is idle for 6 hours.

Duplicate Service Notes:

54520C-03

54522C-03

54540C-03

54542C-03

Situation:

These Oscilloscopes have a "screen saver" feature which turns off the display after a specified idle time. The default for this feature is six hours, but it may be adjusted to as little as one hour or turned on constantly by selecting "infinite".

This feature is located in the Utility menu

Press System menu softkey

Press System Util softkey

Press FP ONTIME HRS softkey and adjust on time using Entry Knob.

Solution/Action:

Keep in mind that this is not a defect in the Oscilloscope but a selectable feature.

DATE: July 1998

ADMINISTRATIVE INFORMATION

N:		
INFORMATION ONLY		
ENTITY:	ADDITIONAL INFORMATION:	
0840	Userís Reference P/N 54542-99017, Pages 11-15 & 11-18.	
	INFORMA ENTITY:	

© 1998 AGILENT TECHNOLOGIES PRINTED IN U.S.A.

