

S E R V I C E N O T E

SUPERSEDES: None

54542A Oscilloscope**Serial Numbers:** 0000A00000 / US99999999**When Power is cycled during an GPIB activity the Oscilloscope will lock up.****Duplicate Service Notes:**

| | |
|-----------|-----------|
| 54520C-04 | 54522C-04 |
| 54540C-04 | 54520A-03 |
| 54522A-03 | 54540A-03 |
| 54542C-04 | |

Situation:

If power is cycled while the instrument is performing operations over GPIB, the instrument will lock-up.

Solution/Action:

Power the instrument down, and while holding down any front panel key, power the instrument back up. This will clear the lock-up problem and allow normal operation of the instrument.

DATE: March 1997

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR:

ENTITY:

ADDITIONAL INFORMATION:

TG

0800

