

S E R V I C E N O T E

SUPERSEDES: None

54600A Oscilloscope

Serial Numbers: 0000A00000 / 3220A06532

Duplicate Service Notes:

54600A-07-S

54601A-07

Possible Shock Hazard

WARNING

Situation:

This condition exists only if the cabinet handle has been removed.

If the cabinet handle has been removed, access to the display unit and a shock hazard is possible. The option 001 is an exception to this.

Solution/Action:

If a unit is to be used in an application where the cabinet handle is removed, then an insulator should be installed in the unit.

To obtain Shock Hazard Kit, order P/N 54600-68714 or contact the Colorado Springs Product Support Department.

DATE: 25 August 1992

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:			
SAFETY			
ACTION CATEGORY:	<input type="checkbox"/> ON SPECIFIED FAILURE <input checked="" type="checkbox"/> AGREEABLE TIME	STANDARDS:	Labor 0.25 Hours
LOCATION CATEGORY:	<input type="checkbox"/> CUSTOMER INSTALLABLE <input type="checkbox"/> ON-SITE <input checked="" type="checkbox"/> SERVICE CENTER	SERVICE INVENTORY:	<input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	USED PARTS:	<input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT
AUTHOR: NCW	ENTITY: 0800	AGILENT RESPONSIBILITY UNTIL: ALWAYS	
		ADDITIONAL INFORMATION:	