

INFORMATION ONLY – DOES NOT COMMUNICATE  
A MODIFICATION OR SAFETY CONDITION

**54825A-09**

# S E R V I C E N O T E

Supersedes:  
None

## 54825A Infiniium Oscilloscopes – 2Gsa/s, 4 Ch, 500MHZ

Serial Numbers: ALL

**This Service note is providing performance verification instructions to Service Centers repairing Infiniium Oscilloscopes. There has been units returning to customers, after repairs were completed, that have had problems operating active probes.**

**Parts Required:**

| P/N     | Description                        | Qty. |
|---------|------------------------------------|------|
| 1156A - | 1.5 GHz active probe for Infiniium | 1    |

### ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

**INFORMATION ONLY**

AUTHOR: MR    PRODUCT LINE: 1A

ADDITIONAL INFORMATION: Customer Satisfaction issue.

© AGILENT TECHNOLOGIES, INC. 2002  
PRINTED IN U.S.A.



May 20, 2002

**Situation:**

In order to provide complete customer satisfaction after repairs have been made to the Front Panel, probe Interface Assemblies, or Acquisition board. Please verify front panel functionality prior to returning unit to customers.

**Solution/Action:**

1. Using a 1156A active probe verify front panel interface functionality, by connecting probe to each channel.
2. When connected to channel, notice that the proper probe has been recognized.
3. Perform Probe User Calibration for each channel.