A MODIFICATION ONLY - DOES NOT COMMUNICATE

5DX-80

SERVICE NOTE

Supersedes: [NONE]

5DX Series II, 2L, 3 and 5000 Systems

Serial Numbers: All

"Automatic" X-ray Safety Test on 5DX Systems with one Loader or one Outer Barrier does not work

Parts Required:

P/N Description Qty.

[NONE]

Situation:

The Automated X-ray Safety Test procedure, included in the 8.2 software release, fails when run on 5DX Systems that only have one loader or one outer barrier.

The test exits before the CE can do the radiation survey.

Solution/Action:

Use the manual X-ray Safety Test Procedure (5021-1979).

This is located on the MTBU website at: http://agilent.com/see/5DX

Select "Product & Safety Notifications"

Select "X-ray Safety Test"

Select "X-ray Safety Test Procedure - Software Release 8.1 and Earlier"

The Automated X-ray Safety test will be corrected in the 8.3 software release.

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR: Guy Sitler PRODUCT LINE: 80

ADDITIONAL INFORMATION:

© AGILENT TECHNOLOGIES, INC. 2005 PRINTED IN U.S.A.

