# S E R V I C E N O T E

SUPERSEDES: None

# 83751A Synthesized Sweeper

**Serial Numbers:** 83751A 0000A00000 / 3610A00261

83751B 0000A00000 / 3610A00166

## **Incorrect password correction**

**Duplicated Service Notes:** 83751B-04

### **Situation:**

At some unknown period in time, the password on the 83751A/B models was incorrectly set by the factory. The password was incorrectly set to 83752. Starting with the prefix/serial numbers listed, the password has been corrected and set to 83751.

Continued

DATE: January 1997

### ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICA	TION:	
INFORMATION ONLY		
AUTHOR:	ENTITY:	ADDITIONAL INFORMATION:
DM	5320	

© 1997 AGILENT TECHNOLOGIES PRINTED IN U.S.A.



1 of 2

Page 2 Service Note 83751A-05

#### **Solution/Action:**

If an 83751A/B is found with the incorrect password, "83752", change the password to "83751".

#### To change the password:

- 1. Press [Shift], [Special], "24" [Hz/s/ENTER].
- 2. At the enter password prompt, enter "83752" [Hz/s/ENTER]. If the password is not accepted, the customer has set a new password and the password should not be changed. If this case see section 8 of the Service Guide for instructions on how to bypass the password if access is required to calibrate the instrument, .
- 3. Use the up/down arrow keys to locate "312 New Password" and press [Hz/s/ENTER].
- 4. At the old password prompt enter "83752" [Hz/s/ENTER]. 5. At the new password prompt enter "83751" [Hz/s/ENTER].

See section 8 of the 83751/2/A/B Service Guide for the full set of instructions for changing the password.