

E8361A-07

S E R V I C E N O T E

Supersedes:
NONE

E8361A PNA Microwave Network Analyzers

Serial Numbers: 0000A00000/9999Z99999

Lid clamps are required for the SOMA 70 assemblies to prevent minor instability sometimes seen on a display trace.

To Be Performed By: Agilent-Qualified Personnel

Parts Required:

P/N	Description	Qty.
E8361-20063	Lid clamp, SOMA 70	2
0515-1862	Machine screw, M3 x 27.5	4

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:			
MODIFICATION RECOMMENDED			
ACTION CATEGORY:	IMMEDIATELY ON SPECIFIED FAILURE X AGREEABLE TIME	STANDARDS:	LABOR: 0.5 Hours
LOCATION CATEGORY:	CUSTOMER INSTALLABLE ON-SITE X SERVICE CENTER	SERVICE INVENTORY: N/A	USED PARTS: X SCRAP RETURN SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL: December 2008	
AUTHOR: MF	PRODUCT LINE: PLWN		
ADDITIONAL INFORMATION: This Service Note applies to the following PNA model(s): E8361A			

© AGILENT TECHNOLOGIES, INC. 2007
PRINTED IN U.S.A.



May 8, 2007

Situation:

Lid clamps are available for the SOMA 70 assemblies to prevent minor instability sometimes seen on a display trace.

Solution/Action:

If the E8361A is being repaired and does not already include lid clamps for the SOMA 70 assemblies, order and install the lid clamps and screws. See page 1 of this Service Note for part numbers and quantities needed. Use the four long screws (0515-1862) to attach the lid clamps (E8361-20063) to the SOMA 70s. For more instructions, refer to “Removing and Replacing the A23 and A24 SOMA 70s” in chapter 7 of the E8361A Service Guide, part number E8361-90001, available on the Agilent.com Website.