

INFORMATION ONLY – DOES NOT COMMUNICATE  
A MODIFICATION OR SAFETY CONDITION

**SN J6802B-03**

**S E R V I C E N O T E**

---

Supersedes:  
None

**J6802B DNA MX Analyzer**

**Serial Numbers: [0000A00000 / 9999Z99999]**

**I**

**Parts Required:**

<b>P/N</b>	<b>Description</b>	<b>Qty.</b>
NPN	BIOS flash CD	1

**ADMINISTRATIVE INFORMATION**

SERVICE NOTE CLASSIFICATION:

**INFORMATION ONLY**

AUTHOR: DM    PRODUCT LINE: 2J

ADDITIONAL INFORMATION:

© AGILENT TECHNOLOGIES, INC. 2006  
PRINTED IN U.S.A.



March 30, 2006

**Situation:**

After replacing the SBC (0960-2446) in the J6802B the system BIOS needs to be updated prior to testing and verification.

**Solution/Action:**

#1 Use a needle or other thin object to open the CDROM door on the J6802B. Insert BIOS CD into the drive and close the door.

#2 Attach a VGA monitor and PS2 keyboard to the connectors on the rear of the instrument. (Note: The connectors are behind the small “door”. See photo )

#3 Power up the unit. When the Menu appears, press the <1> key and then the <Enter> key. After the program writes the new BIOS, it will reboot the instrument.

#4 When the menu appears for the second time, press the <2> key and then the <Enter> key. After the BIOS elements are updated the instrument will reboot again. When the menu appears for the third time, press the <3> key and then power off the unit.

