

PRIORITY SAFETY – REQUIRES IMMEDIATE REPAIR ACTION AND SPECIAL EFFORT TO CONTACT CUSTOMERS

SJ50-11-S

S E R V I C E N O T E

Supersedes:
None

Agilent SJ50 Optical Board Test Systems

Serial Numbers: All

POSSIBLE SHOCK HAZARD

WARNING

Monitor Power Cord insulation can be exposed causing a shock hazard.

To Be Performed By: Agilent-Qualified Personnel Only

Parts Required:

P/N	Description	Qty.
5186-5490	AA safety kit	1

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
PRIORITY SAFETY		
ACTION CATEGORY: IMMEDIATELY	STANDARDS: LABOR: 0.5 Hours	
LOCATION CATEGORY: ON-SITE	SERVICE INVENTORY: SCRAP	USED PARTS: SCRAP
AVAILABILITY: End Of Support		
AUTHOR: Martin Boyce PRODUCT LINE: 80		
ADDITIONAL INFORMATION: 5186-5490 is orderable through SPD (SERVICE PARTS DELIVERY) at 1-800-816-8650.		
Reference the service note number in the activity description field of the SR.		

© AGILENT TECHNOLOGIES, INC. 2005
PRINTED IN U.S.A.



September 13, 2005

Situation:

The Anthro Arm pole is designed to rotate thus the operator of the machine can move the keyboard and monitor to a suitable position . This also enables it to be retracted from the front area of the hood/door of the AOI machine.

The Monitor power cable exits the pole at the top through a slot cut into the side of the pole. If this cable is wrapped around the pole a few times then there is possibility of damaging the cable insulation and exposing a live conductor which would present a potential shock hazard.

Solution/Action:

Please take immediate action to fix or prevent this potential shock hazard by ordering AA safety kit 5186-5490 and follow the installation instructions 5186-5489.

Note: This kit should be ordered together with 'Monitor Power cord Safety kit' 5186-5201 if not already implemented, please refer to Safety Notice SJ50-03-S

Note: Once you have completed the installation of the "AA Safety Kit" fill out and install the Service Note label (Part Number N7200-84366) on the SJ50 System near the serial number plate at the rear of the machine.

- After completion of this Service Note send an email with the SJ50 Serial number and state the Service Note Identification Number to: MTBUSERVICENOTES@agilent.com