


# GSM/W-CDMA SMS Testing with Agilent Wireless Test Managers (WTMs)

Application Note



# Introduction

Two Quick Fixed Engineerings (QFEs) for Agilent Wireless Test Managers (WTMs) can be used to automate GSM/W-CDMA Short Message Service (SMS) testing with the Agilent E5515C Wireless Communications Test Set. This application note explains how to install these QFEs and how to implement GSM or W-CDMA SMS test with WTM.

This application note is only applicable for the E6566C C.02.00 and E6568C C.02.00 with development mode. The SMS testing capability is limited in point-to-point test short message service which is available on both the GSM/GPRS and W-CDMA test applications and lab applications for the E5515C. Microsoft® Visual Studio .NET® 2003 or 2005 is also required.

For more information on SMS capabilities on the 8960 (E5515C) and related WTM products, please refer to the table below.

	TA	LA	WTM
GSM	E1968A E1987A	E6701D or above E6785D or above	E6566C/E6568C
W-CDMA	E1963A E1987A	E6703C or above E6785C or above	E6568C

The E6566C C.02.00 QFE and E6568C C.02.00 QFE can be downloaded from the following link: <http://wireless.agilent.com/rfcomms/dloads/wtm>

# Installation

**Caution:** Currently both of the QFEs are based on the development versions of WTM. The run-time WTM versions do not support the SMS test steps.

**Caution:** If customizations have been made to the original WTM version (E6566C 2.0 or E6568C 2.0), please backup the source codes prior to installing the corresponding QFE. The customized code may be over-written or eliminated during the update process.

1. Verify the WTM version (E6566C 2.0 or E6568C 2.0) installed on the PC.
  - a. Open the E6566C or E6568C run-time program.
  - b. Click on **Help>About**. A message window with the WTM application version information will appear. Refer to Figure 1.




Figure 1. WTM version information.

**Note:** If the version on your PC is not correct, the QFE installation process will not be completed.

2. Install the QFE
3. Double click the QFE installation program (E6566C C.02.00 QFE2.exe or E6568C C.02.00 QFE2.exe) to initiate the installation process. Follow the InstallShield Wizard to complete the installation. See Figures 2 to 4.




Figure 2. Start the InstallShield.




Figure 3. Begin the installation.




Figure 4. Installation completed.

#### 4. Database alignment

- a. Open the WTM project (“Project For E6566C GSM GPRS EGPRS” or “Project For E6568C WCDMA GSM GPRS EGPRS”) in the Visual Studio .NET.
- b. Click on the **Agilent WTM Add Wireless Test** button, the Add Wireless Test Wizard window will open. Choose the **Align database test code>Next** and go through the wizard. See Figure 5.




Figure 5. Add Wireless Test Wizard.

5. Rebuild the Visual Studio .NET project. A new run-time application will be generated and the old one will be replaced automatically.

## SMS Testing

There are four SMS-related test steps in these two QFEs.

1. GSM/GPRS/EGPRS SMS mobile terminated
2. GSM/GPRS/EGPRS SMS mobile originated
3. W-CDMA SMS mobile terminated
4. W-CDMA SMS mobile originated

In this section, we will introduce how to set parameters for each test step, and how to create a test plan for SMS testing.

## Parameter setting

There are several parameters for each test step. How to set these parameters depends on what kind of tests you are performing. Below are definitions for each parameter.

### 1. W-CDMA SMS mobile terminated

#### a. Transportation

*Choose the domain in which the SMS messages are sent.*

**Default value:**

CS domain

**Value range:**

CS domain / PS domain

#### b. Content

*Choose or create the message content to be sent to the mobile station.*

**Default value:**

Text1

**Value range:**

Text1 / Text2 / Custom Text / Custom Test File:

***Text1***

“01234567890ABCDEFGHIJKLMNQRSTUUVWXYZabcdefghijklmnop  
nopqrstuvwxyz”

***Text2***

“Agilent Technologies, your partner in wireless solutions.”

***Customer text***

The text sent in the SMS message is customized in the “Custom Text” parameter

***Customer text file***

The text sent in the SMS message is customized in the specific .txt file, which can be found in the “TestData” file under the WTMS’s installation directory. For example: C:\Program Files\Agilent\WirelessTestManager\E6568C\TestData

#### c. Custom text

*Customize the SMS message content that will be sent when the “Content” parameter is set to **Customer Text***

**Default Value:**

“Enter your text here”

**Value range:**

7 bit ACSII characters up to 160 characters

**Note:** The maximum length of the custom text is 50 characters. To send more than 50 characters, please edit the custom text file under the “testdata” folder.

**d. User input for pass/fail**

Define the way by which this step is determined to pass or fail. If **Yes** is selected, users have to decide the Pass/Fail manually using the following form. If **No** is selected, the result is decided automatically. See Figure 6.




Figure 6. User input for SMS mobile Originated Pass/Fail message box

**Default value:**

No

**Value range:**

Yes / No

**e. Timeout of 8960 sending SMS**

**Default value:**

10

**Value range:**

0 to 60

**f. Wait for MT SMS setup to compete**

Specify how long to wait (in milliseconds) for all MT SMS setup parameters to be set to instrument

**Default value:**

0

**Value range:**

0 to 10000

**2. W-CDMA SMS mobile originated**

**a. Loopback**

If this parameter is set to **Yes**, the test set will loop back the message it receives from the mobile station. If set to **No**, the test set only receives what the mobile station sends.

**Default value:**

Off

**Value range:**

On / Off

**b. Timeout of 8960 receiving SMS**

**Default value:**

10

**Value range:**

0 to 10000

**c. User input for pass fail**

Same as the equivalent in the W-CDMA SMS mobile terminated step

**Default value:**

No

**Value range:**

Yes / No

**d. Operator interaction required**

*Specify whether or not operator interaction is required when WTM requires an action from the DUT. When this parameter is set to **Yes**, a message is displayed to the user to perform the desired action. When set to **No**, the “Data Connection DUT Commands with Specs” table is used to define the serial commands to send to the DUT for the desired action.*

**Default value:**

Yes

**Value range:**

Yes / No

**e. DUT timeout for received command**

*Specify the amount of time to wait during a “Receive from DUT” action for the information to be returned on the serial connection*

**Default value:**

2

**Value range:**

0 to 60

**f. Send SMS DUT command with specs**

*Refer to “GSM BS Initiated Call DUT Commands with Specs” in the “GSM Base Station Initiated Call” step*

**Default Value:**

None

**Value range:**

None

**g. Wait for MO SMS setup to complete**

*Specify how long to wait (in milliseconds) for all MO SMS setup parameters to be set to instrument*

**Default value:**

0

**Value range:**

0 to 10000

**3. GSM/GPRS/EGPRS SMS mobile terminated**

**a. GGE transportation**

*Define the protocol layer via which the point-to-point SMS message is sent*

**Default value:**

GSM

**Value range:**

GSM / GPRS

**b. Content**

*Same as the equivalent in the W-CDMA SMS mobile terminated step*

**Default value:**

Text1

**Value range:**

Text1 / Text2 / Custom Text / Custom Text File

- c. Custom text**  
*Same as the equivalent in the W-CDMA SMS mobile terminated step*  
**Default value:**  
"Enter your text here"  
**Value range:**  
7 bit ACSII characters up to 160 characters
- d. User input for pass/fail**  
*Same as the equivalent in the W-CDMA SMS mobile terminated step*  
**Default value:**  
No  
**Value range:**  
Yes / No
- e. Timeout of 8960 sending SMS**  
**Default value:**  
10  
**Value range:**  
0 to 60
- f. Wait for MT SMS setup to complete**  
*Same as the equivalent in the W-CDMA SMS mobile terminated step*  
**Default value:**  
0  
**Value range:**  
0 to 10000

#### **4. GSM GPRS EGPRS SMS mobile originated**

- a. Loopback**  
*Same as the equivalent in the W-CDMA SMS mobile originated step*  
**Default value:**  
On  
**Value range:**  
On / Off
- b. Timeout of 8960 receiving SMS**  
**Default value:**  
10  
**Value range:**  
0 to 10000
- c. User input for pass/fail**  
*Same as the equivalent in the W-CDMA SMS mobile terminated step*  
**Default value:**  
No  
**Value range:**  
Yes / No

- d. Operator interaction required**  
*Same as the equivalent in the W-CDMA SMS mobile originated step*  
**Default value:**  
Yes  
**Value range:**  
Yes / No
- e. DUT timeout for received command**  
*Same as the equivalent in the W-CDMA SMS mobile originated step*  
**Default value:**  
2  
**Value range:**  
0 to 60
- f. Send SMS DUT command with specs**  
*Same as the equivalent in the W-CDMA SMS mobile originated step*  
**Default value:**  
None  
**Value range:**  
None
- g. Wait for MO SMS setup to complete**  
*Same as the equivalent in the W-CDMA SMS mobile originated step*  
**Default value:**  
0  
**Value range:**  
0 to 10000

**Note:** Supports 160 SMS characters, including MT and MO. If user wants to send more than 160 SMS characters in MO, the "User Input for Pass/Fail" must be set to **Yes**, which means the pass/fail must be indicated "manual."

## Create SMS Test Plan

These new SMS test steps provide the capability to test DUT SMS functionality. Examples of typical test plans are provided.

### 1. GSM plans

#### a. Test plan I

*This test plan can be used to check the SMS ability of the DUT within the GSM transportation*

**Step 1:**

GSM base station initiated call

**Step 2:**

GSM end call

**Step 3:**

GSM/GPRS/EGPRS SMS mobile terminated or GSM/GPRS/EGPRS SMS mobile originated

#### b. Test plan II

*The following plan can be used to check the SMS ability of the DUT over the voice call connection within GSM transportation*

**Step 1:**

GSM base station initiated call

**Step 2:**

GSM/GPRS/EGPRS SMS mobile terminated or GSM/GPRS/EGPRS SMS mobile originated

**Step 3:**

GSM end call

### 2. GPRS plan

*This test plan can be used to check the SMS ability of the DUT within the GPRS transportation. The first and second are steps to ensure that the connection status is "Attached" between the DUT and the E5515C test set*

**Step 1:**

GPRS start data connection

**Step 2:**

GPRS end data connection

**Step 3:**

GSM/GPRS/EGPRS SMS mobile terminated or GSM/GPRS/EGPRS SMS mobile originated

### 3. W-CDMA CS domain plan

#### a. Test plan I

*This test plan can be used to check the W-CDMA SMS ability of the DUT over an existing connection in the CS domain*

**Step 1:**

W-CDMA origination

**Step 2:**

W-CDMA SMS mobile terminated or W-CDMA SMS mobile origination

**Step 3:**

W-CDMA base station release

#### b. Test plan II

*This test plan can be used to check the W-CDMA SMS ability of the DUT in the CS domain*

**Step 1:**

W-CDMA registration ("Registration PS Domain Information" should be set to **Info Absent** and "Registration IMSI Attach Flag" should be set to **Set**)

**Step 2:**

W-CDMA SMS mobile terminated or W-CDMA SMS mobile origination

### 4. W-CDMA PS domain plan

*This test plan can be used to check the W-CDMA SMS ability of the DUT in the PS domain*

**Step 1:**

W-CDMA registration ("Registration PS Domain Information" should be set to **Info Present** and "Registration IMSI Attach Flag" should be set to **Set**)

**Step 2:**

W-CDMA SMS mobile terminated or W-CDMA SMS mobile origination



### Agilent Email Updates

[www.agilent.com/find/emailupdates](http://www.agilent.com/find/emailupdates)

Get the latest information on the products and applications you select.



### Agilent Direct

[www.agilent.com/find/agilentdirect](http://www.agilent.com/find/agilentdirect)

Quickly choose and use your test equipment solutions with confidence.

### Remove all doubt

Our repair and calibration services will get your equipment back to you, performing like new, when promised. You will get full value out of your Agilent equipment throughout its lifetime. Your equipment will be serviced by Agilent trained technicians using the latest factory calibration procedures, automated diagnostics and genuine parts. You will always have the utmost confidence in your measurements.

Agilent offers a wide range of additional expert test and measurement services for your equipment, including initial start-up assistance, onsite education and training, as well as design, system integration, and project management.

For more information on repair and calibration services, go to:

[www.agilent.com/find/removealldoubt](http://www.agilent.com/find/removealldoubt)

### [www.agilent.com](http://www.agilent.com)

For more information on Agilent Technologies' products, applications or services, please contact your local Agilent office. The complete list is available at:

[www.agilent.com/find/contactus](http://www.agilent.com/find/contactus)

#### Americas

Canada	(877) 894-4414
Latin America	305 269 7500
United States	(800) 829-4444

#### Asia Pacific

Australia	1 800 629 485
China	800 810 0189
Hong Kong	800 938 693
India	1 800 112 929
Japan	0120 (421) 345
Korea	080 769 0800
Malaysia	1 800 888 848
Singapore	1 800 375 8100
Taiwan	0800 047 866
Thailand	1 800 226 008

#### Europe & Middle East

Austria	0820 87 44 11
Belgium	32 (0) 2 404 93 40
Denmark	45 70 13 15 15
Finland	358 (0) 10 855 2100
France	0825 010 700*
Germany	*0.125€ fixed network rates 01805 24 6333**
	**0.14€/minute
Ireland	1890 924 204
Israel	972-3-9288-504/544
Italy	39 02 92 60 8484
Netherlands	31 (0) 20 547 2111
Spain	34 (91) 631 3300
Sweden	0200-88 22 55
Switzerland (French)	41 (21)8113811(Opt2)
Switzerland (German)	0800 80 53 53 (Opt 1)
United Kingdom	44 (0) 118 9276201

Other European Countries:

[www.agilent.com/find/contactus](http://www.agilent.com/find/contactus)

Revised: October 24, 2007

Product specification and descriptions in this document subject to change without notice.

Microsoft and Visual Studio .NET are U.S. registered trademarks of Microsoft Corporation.

© Agilent Technologies, Inc. 2008  
Printed in USA, January 11, 2008  
5989-7864EN



**Agilent Technologies**