

## S E R V I C E N O T E

SUPERSEDES: NONE

**Agilent 4285A Precision LCR Meter**

Serial Numbers: 3041J02755 / 3041J02901

**The message "SCANNER DATA CSUM ERROR" is displayed with Option 301.****Duplicate Service Notes:** 4284A-13 Serial Numbers: 2940J11332 / 2940J12222**To Be Performed By:** Agilent-Qualified Personnel**Parts Required:**

P/N	Description	Quantity
04278-66541	SCANNER I/F	1

**Situation:**

The 4285A option 301 Scanner Interface function may fail as follows. The message "SCANNER DATA CSUM ERROR" is displayed when the 4284A is turned on.

**Solution / Action:**

Replace SCANNER I/F board with a new A41 board.

DATE: October 2000

## ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:			
<b>MODIFICATION RECOMMENDED</b>			
ACTION CATEGORY:	<input type="checkbox"/> IMMEDIATELY <input checked="" type="checkbox"/> ON SPECIFIED FAILURE <input type="checkbox"/> AGREEABLE TIME	STANDARDS:	LABOR 1.0 Hours
LOCATION CATEGORY:	<input type="checkbox"/> CUSTOMER INSTALLABLE <input type="checkbox"/> ON-SITE <input checked="" type="checkbox"/> SERVICE CENTER	SERVICE INVENTORY:	<input checked="" type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	USED PARTS:	<input type="checkbox"/> RETURN <input checked="" type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT
AUTHOR: TK	ENTITY: 3355	AGILENT RESPONSIBLE UNTIL: October 2002	
		ADDITIONAL INFORMATION:	

