

S E R V I C E N O T E

SUPERSEDES: None

54600A Oscilloscope

Serial Numbers: 0000A00000 / 3227A07006

Lubrication leaking from behind control knobs

Duplicate Service Notes:

54600A-09

54601A-09

Situation:

Lubrication leaks from front panel controls along shaft then down front panel from behind knobs.

Solution/Action:

Order required number of wool felt washers, P/N 5081-7740, or contact the Colorado Springs Product Support Department. To install felt washers, remove control knobs, slide washer onto control shaft, press washer into place using a small screwdriver.

DATE: 04 December 1992

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
MODIFICATION AVAILABLE		
ACTION CATEGORY:	AGREEABLE TIME	<input checked="" type="checkbox"/> PERFORMANCE ENHANCEMENT <input type="checkbox"/> SERVICE/RELIABILITY ENHANCEMENT
LOCATION CATEGORY:	<input checked="" type="checkbox"/> CUSTOMER INSTALLABLE <input type="checkbox"/> ON-SITE <input checked="" type="checkbox"/> SERVICE CENTER	AVAILABLE UNTIL: December 1993
AUTHOR: NCW	ENTITY: 0800	ADDITIONAL INFORMATION: