

S E R V I C E N O T E

SUPERSEDES: None

83751B Synthesized Sweeper

Serial Numbers: 83751A 0000A00000 / 3610A00261
83751B 0000A00000 / 3610A00166

Incorrect password correction

Duplicated Service Notes: 83751A-05

Situation:

At some unknown period in time, the password on the 83751A/B models was incorrectly set by the factory. The password was incorrectly set to 83752. Starting with the prefix/serial numbers listed, the password has been corrected and set to 83751.

Continued

DATE: January 1997

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR:

DM

ENTITY:

5320

ADDITIONAL INFORMATION:



Solution/Action:

If an 83751A/B is found with the incorrect password, "83752", change the password to "83751".

To change the password:

1. Press [Shift], [Special], "24" [Hz/s/ENTER].
2. At the enter password prompt, enter "83752" [Hz/s/ENTER]. If the password is not accepted, the customer has set a new password and the password should not be changed. If this case see section 8 of the Service Guide for instructions on how to bypass the password if access is required to calibrate the instrument, .
3. Use the up/down arrow keys to locate "312 New Password" and press [Hz/s/ENTER].
4. At the old password prompt enter "83752" [Hz/s/ENTER]. 5. At the new password prompt enter "83751" [Hz/s/ENTER].

See section 8 of the 83751/2/A/B Service Guide for the full set of instructions for changing the password.