86100A-06

SERVICE NOTE

Supersedes:

86100A INFINIIUM DCA

Serial Numbers: all

Module not recognized by mainframe or module communication error

To Be Performed By: Agilent-Qualified Personnel or Customer

Parts Required:

P/N Description Qty.

86100-66518 Distribution Assembly (A12) 1

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:		
MODIFICATION RECOMMENDED		
ACTION CATEGORY:	[[]] IMMEDIATELY x ON SPECIFIED FAILURE [[]] AGREEABLE TIME	STANDARDS: LABOR: 0.5 Hours
LOCATION CATEGORY:	[[]] CUSTOMER INSTALLABLE [[]] ON-SITE x SERVICE CENTER	SERVICE [[]] RETURN USED [[]] RETURN INVENTORY: x SCRAP PARTS: x SCRAP [[]] SEE TEXT [[]] SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL:
AUTHOR: BMH	PRODUCT LINE: 8F	
ADDITIONAL INFORMATION:		

© AGILENT TECHNOLOGIES, INC. 2002 PRINTED IN U.S.A.



Page 2 of 2 86100A-06

Situation:

The clock line to the two modules does not have adequate isolation so reflections sometimes cause errors in read and write operations. The problems are intermittent.

Solution/Action:

Replace Distribution assembly, A12 with new design assembly