

S E R V I C E N O T E

SUPERSEDES: NONE

E2929A PCI-X Master Target Test Card, 133MHz

Serial Numbers: DE40300101 / DE40300192

USB port draws excessive current from the Host System**To Be Performed By:** Agilent-Qualified Personnel**Parts Required:** None**Situation:**

If the User connects the E2929A USB port to the host, up to 3 Amperes are drawn from the hosts 5V. This may lead to a defective USB port on the host system.

Solution / Action:

Remove the part E401 from the E2929A.

Visit the URL

'<http://www.bvsg.germany.agilent.com/pl24/marketing/webcoe/intern/E2920A/Mode/Mode.html>' for further information.

DATE: November 2000

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:			
MODIFICATION RECOMMENDED			
ACTION CATEGORY:	<input checked="" type="checkbox"/> IMMEDIATELY <input type="checkbox"/> ON SPECIFIED FAILURE <input type="checkbox"/> AGREEABLE TIME	STANDARDS: LABOR 0.5 Hours	
LOCATION CATEGORY:	<input type="checkbox"/> CUSTOMER INSTALLABLE <input type="checkbox"/> ON-SITE <input checked="" type="checkbox"/> SERVICE CENTER	SERVICE INVENTORY: <input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT	USED PARTS: <input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE		AGILENT RESPONSIBLE UNTIL: Product Support Life
AUTHOR: RS	ENTITY: B100	ADDITIONAL INFORMATION:	

