

INFORMATION ONLY – DOES NOT COMMUNICATE
A MODIFICATION OR SAFETY CONDITION

E4446A-03

S E R V I C E N O T E

Supersedes:
NONE

PSA Series Spectrum Analyzer

Serial Numbers: [0000A00000 / 9999Z99999]

Several CPU Replacement assemblies P/N E4406-60060 were inadvertently shipped with a Valid Serial Number loaded in the CPU Board. An all zero serial number is required. This is needed for the CPU Initialization portion of the adjustment software to change the serial number to the actual serial number of the instrument.

Parts Required:

P/N	Description	Qty.
-----	-------------	------

NONE

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR: BNN PRODUCT LINE: 12

ADDITIONAL INFORMATION:

© AGILENT TECHNOLOGIES, INC. 2003
PRINTED IN U.S.A.



Agilent Technologies

June 23, 2003

Situation:

Several CPU Replacement assemblies P/N E4406-60060 were inadvertently shipped with a Valid Serial Number loaded in the CPU Board. An all zero serial number is required. This is needed for the CPU Initialization portion of the adjustment software to change the serial number to the actual serial number of the instrument.

Solution/Action:

Please contact the Signal Analysis Division to obtain the Agilent Confidential procedure for changing a valid serial number.

Please contact sa-support_pgu@agilent.com