

MODIFICATION RECOMMENDED –  
CORRECTS MANUFACTURING OR DESIGN DEFECTS

**E5022B-02**

# **S E R V I C E N O T E**

Supersedes:  
NONE

## E5022B Hard Disk Read/Write Test System

**Serial Numbers:** See Action/Solution

**Measurements related to the E5038A operation may be performed incorrectly**

**To Be Performed By:** Agilent-Qualified Personnel

**Parts Required:** See Action/Solution

## ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:			
<b>MODIFICATION RECOMMENDED</b>			
ACTION CATEGORY:	<input type="checkbox"/> IMMEDIATELY <input checked="" type="checkbox"/> ON SPECIFIED FAILURE <input type="checkbox"/> AGREEABLE TIME	STANDARDS: LABOR: 0.5 Hours	
LOCATION CATEGORY:	<input type="checkbox"/> CUSTOMER INSTALLABLE <input checked="" type="checkbox"/> ON-SITE <input type="checkbox"/> SERVICE CENTER	SERVICE INVENTORY: <input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT	USED PARTS: <input checked="" type="checkbox"/> RETURN <input type="checkbox"/> SCRAP <input type="checkbox"/> SEE TEXT
AVAILABILITY:	PRODUCT'S SUPPORT LIFE	AGILENT RESPONSIBLE UNTIL: Oct 2006	
AUTHOR: KW		PRODUCT LINE: WN	
ADDITIONAL INFORMATION:			

© AGILENT TECHNOLOGIES, INC. 2004  
PRINTED IN U.S.A.



October 19, 2004

**Situation:**

Some of the E5038A specified in Solution/Action part serial number may have an unusual heating problem. The following measurements may be performed incorrectly due to the problem.

- Baseline Measurement
- Baseline Popping Measurement
- Popcorn Noise Measurement (Sampling Method)
- Other measurements using Histogrammer

This problem does not happen when the E5022 system is initialized shortly after the VXI mainframe is switched on.

**Solution/Action:**

Replace the E5038A module with a new one.

E5038A module serial number: 0000A00000 to 9999Z99999

P/N	Description	Qty.
E5038-69001	Para Test Module	1