

PRIORITY SAFETY – REQUIRES IMMEDIATE REPAIR ACTION AND SPECIAL EFFORT TO CONTACT CUSTOMERS

**E6651A-01-S**

**S E R V I C E N O T E**

Supersedes:  
NONE

**E6651A Mobile WiMAX Test Set**

**Serial Numbers: KR47220101 to KR47220140 inclusive and  
KR47380101 to KR47380110 inclusive.**

**POSSIBLE HANDLING HAZARD**

**WARNING**

**Defective handle may cause personal injury or equipment damage**

**To Be Performed By: Agilent-Qualified Personnel Only**

**Parts Required:**

<b>P/N</b>	<b>Description</b>	<b>Qty.</b>
E6651-61801	Handle Repair Kit	1

**ADMINISTRATIVE INFORMATION**

SERVICE NOTE CLASSIFICATION:		
<b>PRIORITY SAFETY</b>		
ACTION CATEGORY: X IMMEDIATELY	STANDARDS LABOR: 1.25 Hours	
LOCATION CATEGORY: X ON-SITE X SERVICE CENTER	SERVICE INVENTORY: <input type="checkbox"/> RETURN <input type="checkbox"/> SCRAP X SEE TEXT	USED PARTS: <input type="checkbox"/> RETURN X SCRAP <input type="checkbox"/> SEE TEXT
AVAILABILITY: ALWAYS	NO CHARGE AVAILABLE UNTIL: ALWAYS	
AUTHOR: AS	PRODUCT LINE: PN	
ADDITIONAL INFORMATION:		

© AGILENT TECHNOLOGIES, INC. 2008  
PRINTED IN U.S.A.



April 24, 2008

**Situation:**

**There are 4 screws holding each side strap (carry) handle in place on each unit. There are two such handles on each instrument, so eight screws involved. These screws may loosen over time and the strap handle could become detached from the chassis.**

**Solution/Action:**

Using the repair kit identified on page 1, the 8 handle screws will be replaced with new screws and an improved handle bush.

Service Inventory – this service note does not affect any existing service inventory.