# A MODIFICATION ONLY - DOES NOT COMMUNICATE

J2126A-02

## S E R V I C E N O T E

Supersedes: None

### AGILENT J2126A Transmission Test Set

Serial Numbers: [0000A00000 / 9999Z99999]

Broken ceramic inserts on the optical adapters.

TD 4	т.	•	•
<b>Parts</b>	Keg	uire	e <b>a</b> :

P/N	Description	Type
1005-0998	Optical Adapter	FC/PC
1005-0999	Optical Adapter	ST
1005-1000	Optical Adapter	$\mathbf{SC}$

#### **Situation:**

When connecting or disconnecting an optical fiber cable to the test set, ceramic inserts on the optical adapters may break.

#### **Solution/Action:**

A new optical adapter is available. If a ceramic insert is broken, use the appropriate replacement optical adapter. (See parts.)

#### ADMINISTRATIVE INFORMATION

INFORMATION ONLY

AUTHOR: JH PRODUCT LINE: PY

ADDITIONAL INFORMATION:

© AGILENT TECHNOLOGIES, INC. 2002 PRINTED IN U.S.A.



January 31, 2002

Page 2 of 2 J2126A-2