

INFORMATION ONLY – DOES NOT COMMUNICATE
A MODIFICATION OR SAFETY CONDITION

SN J6800A-05

S E R V I C E N O T E

Supersedes:
None

J6800A Analyzer

Serial Numbers: [0000A00000 / 9999Z99999]

If it is necessary to replace the CDROM drive in the J6800A a special tool is required to properly align the CDROM drive in the mounting bracket.

Parts Required:

P/N	Description	Qty.
T-308355	Alignment tool	1

ADMINISTRATIVE INFORMATION

SERVICE NOTE CLASSIFICATION:

INFORMATION ONLY

AUTHOR: DM PRODUCT LINE: 2J

ADDITIONAL INFORMATION:

© AGILENT TECHNOLOGIES, INC. 2004
PRINTED IN U.S.A.



Agilent Technologies

August 19, 2004

Situation:

Tool T-308355 is available from doug_meyer@agilent.com

Solution/Action:

To assure proper positioning of the CD-RW drive onto the bracket is to make a flat, 0.8 mm thick tool (T-308355) which is laid onto the surface of the sheet-metal against which the drive is mounted. Then, place the drive onto the bracket sandwiching the tool between the drive and the bracket. Assure that the drive is resting in contact with the tool. Then install the four M2 screws holding the drive onto the bracket. Then, slide the tool out, which should leave a 0.8 mm gap between the underside of the drive and the bracket. You can see this small gap between the bracket and the drive in the picture below. .

