Information Only Service Note

Supersedes: N5182B-05

N5182B X-Series MXG Vector Signal Generator

Serial Numbers: ALL

The Problem – Installing a new A3 RF Assembly during a repair or upgrade requires the installation of firmware version B.01.65 or newer.

Parts Required:

P/N Description Qty.

NONE

ADMINISTRATIVE INFORMATION

[[]] Calibration Required

X Calibration NOT Required

PRODUCT LINE: 15 AUTHOR: MM

ADDITIONAL INFORMATION:



Situation:

The X-Series family of RF signal sources has recently had its A3 RF Assemblies updated. The updates have incorporated a few design changes that require firmware version B.01.65 or newer. However, the replacement kits for these new revisions have maintained all the same ordering part numbers.

These new assemblies require firmware version B.01.65 or newer to function properly. Without this version of firmware instrument configurations, installed options, service software, and self-test errors can occur.

Solution/Action:

Under normal circumstances it is always recommended that the latest firmware be installed in Keysight products to maintain their most current functionality and proper operation.

With the installation of any of the new kit part numbers listed below, firmware version B.01.65 or newer must also be installed.

| Description | New Kit Part # | Exchange Kit Part # | |
|--------------------------------|----------------|---------------------|--|
| A3 RF Assembly Replacement Kit | N5180-60421 | N5180-69421 | |
| | N5180-60422 | N5180-69422 | |
| | N5180-60423 | N5180-69423 | |
| | N5180-60424 | N5180-69424 | |
| | N5180-60425 | N5180-69425 | |

To download the latest version of the MXG firmware go to http://www.keysight.com/find/ss_firmware

Revision History:

| Date | Service Note Revision | Author | Reason for Change |
|-------------|--------------------------|----------------|---------------------|
| 11 Aug 2017 | 01 | Allen Stephens | As Published |
| 16 Oct 2018 | 02 | Mike Medley | Updated information |