


# Properly Powering On and Off Multiple Power Inputs in Embedded Designs

## Application Note



*This is the first in a series of application notes that addresses power optimization, characterization, and simulation challenges in embedded designs.*

### Introduction

If you are designing embedded systems, you face various power optimization and power characterization hurdles throughout the design process. You know what you want to output, simulate and measure—but you need a whole “toolbox” of instruments and hardware to do the job. Properly configuring the various tools into an accurate, dependable solution can be difficult and time consuming. When you need to rerun a test later, you may have to repeat the whole time-intensive process of configuring your test setup.

The challenges you face can be divided into three categories: properly powering on and off multiple power inputs, characterizing power needs under dynamic load conditions and simulating real-world power conditions.

This application note will focus on properly powering on and off multiple power inputs in an embedded design. We will discuss a simple way to overcome power sequencing challenges without the need for a costly toolbox of hardware.



## Properly Powering On and Off Multiple Power Inputs

Embedded systems can be made up of any combination of microcontrollers, FPGAs, ASICs and memory chips. These individual integrated circuits often have multiple power input requirements that must be properly sequenced on and off to prevent latch-up. Precise slew rates on each input at power on or power off may be required as well.

Latch-up may cause a wasteful initial surge of current at turn on, or it may be severe enough to inflict permanent damage to the semiconductor device. Even without the fear of latch-up, powering on your design can become complicated if the embedded system consists of multiple integrated circuits where some become active instantly and others require some time to configure or execute a start-up routine that must be retrieved from a memory device. In this situation, there may be power optimization advantages to establishing precise sequencing across the integrated circuits.

Existing solutions for providing multiple power inputs, sequencing and slew rates include fixed regulator circuits and programmable power supplies. In the initial design stage, you often will be able to leverage fixed regulator circuits from development boards or past designs. If you implement fixed regulators early in the design, you do not have the ability to adjust input sequencing timing and slew rates for minimum current draw at turn-on. Also, with fixed regulators you still need some type of measurement device to perform precise power measurements for optimization and troubleshooting during the design process.

Using programmable power supplies provides the flexibility to adjust input power settings during the design process for power optimization. Sequencing power supplies on and off with software requires extra time for programming, and it also injects a timing-error deviation. The problem with the software-only approach is your sequence delay accuracies are dependent on a computer operating system that shares processor time with multiple applications, so accuracy can vary by more than 10 ms. You could employ a real-time operating system, but this is a costly measure that still has limitations in timing accuracy. The other option is to employ hardware-timed switching. This comes with a high time overhead and extra cost, since you need to either create custom hardware or configure a DIO card to accurately time switch closures. These sequencing configurations often need to be reconfigured each time the design changes or a new design is started.

Setting up various slew rates on power inputs when you are using fixed regulator circuits requires some type of RC network at the output. Once again, this is an inflexible solution since it cannot be easily adjusted. Controlling slew rate on programmable power supplies may be possible through programming if you are working with a high-performance supply. Otherwise, you will need to use some type of RC network on the output of the supplies.

## Product Features

### Solution

The power input challenges embedded design engineers face can be solved with the Agilent N6705A DC Power Analyzer. The N6705A provides four programmable power supply outputs each with dynamic measurement capability. Each of the four output's characteristics are determined by which plug-in power module is used for that output. There are 21 different power modules available for the N6705A. Table 1 on page x shows a list of suggested modules for the N6705A and their key specifications that make them a good fit for embedded design development.

The N6705A's power outputs have built-in sequencing capabilities. Sequencing time delays can range between 0 and 1 s in 1-ms steps or 0 and 1000 s in 1-s steps. The sequence timing is all done in the hardware of the instrument, which guarantees a high level of accuracy and repeatability. Precision slew rate control on each channel, as fast as 20  $\mu$ s per volt, allows you to set voltage ramp up times on a per-channel basis. Other N6705A features that are applicable to embedded design:

- **Oscilloscope-like display** that can show voltage, current and power versus time on multiple channels. This feature allows you to view in real time the voltage, current and power events of your designs.
- **Built-in data logger** that continuously logs time-stamped data to a large color display and to a file. You can log data on all four outputs at the same time. Data log files can be saved to internal memory or to an external USB memory drive.
- **Built-in waveform functions and arbitrary waveform capability.** You can define an arbitrary waveform with up to 64k points.
- **High-accuracy voltage and current measurement capability.** Accurate current measurement capability down to the microampere level.

The following provides a detailed example of using the N6705A to properly power on an embedded design to lower the turn-on power draw of the design.

### Example: Properly Powering On an Embedded Design

The embedded design for this example uses an FPGA, flash memory chip and various peripheral devices. The FPGA has three power inputs (VCCINT, VCCAUX, and VCCO), two of which have sequencing requirements (VCCINT and VCCAUX). The fourth power input on the embedded design powers the flash memory and peripheral devices (VPER). The memory chip needs to be fully powered up before the FPGA, because the FPGA uses the flash memory for configuration, so VPER is the first to be sequenced on. The whole setup is shown in **Figure 1**.




Figure 1. FPGA circuit test setup

The particular FPGA that is being used in this example does not have strict sequencing requirements, meaning if sequencing is not used the FPGA will not be damaged. However, if the  $V_{CCINT}$  is turned on before or at the same time as  $V_{CCAUX}$ , the FPGA will draw a surplus core current at turn on. The surplus current draw will wear down battery power faster and could force the power distribution designer to use a higher-current-handling

power-hungry regulator. **Figure 2** shows the sequencing, or Output On/Off Delay, setup screen of the N6705A. Notice  $V_{CCINT}$  is sequenced to turn on 1 ms before  $V_{CCAUX}$  on the N6705A. As a result, we can see on the N6705A's scope display an undesirable surplus current spike occurs at the core supply ( $V_{CCINT}$ ) during turn-on because it was powered on before  $V_{CCAUX}$ .





Figure 2. Output sequencing settings and surplus core current at turn on

**Figure 3** shows the proper sequencing to avoid the surplus current spike of ICCINT at turn-on (left) and the output core current (right).










Figure 3. Output sequencing settings and core current at turn-on

To achieve the ramp rate requirements for  $V_{CCINT}$  and  $V_{CCO}$  (see Figure 1), the slew rates for channels 1 and 2 were adjusted. **Figure 4** shows the N6705A display for changing a channel's slew rate, which is expressed in volts per second (V/s). Below the slew rate settings screen is the rising slew rate of channel 1 and 2 on the N6705A outputs. The rise time is captured using the markers for the display.



**Figure 4.** Core voltage and I/O voltage slew rate settings

To ensure successful power-on, the FPGA power supplies must rise through their respective threshold-voltage ranges with no dips. **Figure 5** displays each output from the N6705A with proper sequencing and ramp rates at turn-on time. Each output presents a smooth rise of voltage that is free of dips and other erratic behavior. Figure 5 also lists the power modules used for the example FPGA circuit tests. Since the example circuit uses low power (less than 2 A), any module from the N675xA Series or N676xA Series is a good fit for this demonstration. Up/down output speed, measurement accuracy, and output power capabilities are the main features you need to consider when choosing the proper N6705A power modules for your specific embedded system design needs. Refer to **Table 1** on page 7 for information regarding recommended power modules and their specifications.



**Figure 5.** Power module voltages at turn-on

## Sequencing power inputs of more than four supplies

If the embedded design requires more than four separate power supply inputs, you can sequence multiple N6705A mainframes together. You can easily do this with the user-configurable digital I/O ports located on the back of the mainframe. The latency involved when communicating between multiple mainframes is trivial compared to the rise time of the power modules and the 1-ms sequencing step size. No programming or code writing is needed to take advantage of this feature.

## Conclusion

N6705A DC Power Analyzer is an all-in-one toolbox for quickly and easily addressing power optimization, characterization and simulation challenges in embedded designs. Powering on and off embedded designs presents a challenge because integrated circuits such as FPGAs, microcontrollers, and ASICs often have power input sequencing and slew rate requirements. If these turn-on requirements are not met, it could cause damage to the embedded design (latch-up) or cause an unnecessary excessive power draw at turn-on.

The N6705A provides built-in adjustable sequencing and slew rate capability across its four outputs and across mainframes. You can access these built-in capabilities easily through the front panel to protect your design from damage and gain the flexibility to fine tune the turn on and off process for power optimization throughout the design process. The optimized power input timing data that is obtained from the N6705A can be employed when the power distribution portion of the design is done to ensure minimum power draw at turn on and off.



**Table 1:**  
Key specifications of N6705A modules  
ideally suited for embedded design.

		N6751A/52A	N6754A	N6761A/62A
<b>DC output ratings</b>	Voltage	50 V	60 V	50 V
	Current	5 A / 10 A	20 A	1.5 A / 3 A
	Power	50 W / 100 W	300 W	50 W / 100 W
<b>Max up-programming time with full R load</b> (Time from 10% to 90% of total voltage)	Voltage change	0 to 10 V	0 to 15V	0 to 10 V
	Time	0.2 ms	0.35 ms	0.6 ms
	Voltage change	0 to 50 V	0 to 60 V	0 to 50 V
	Time	1.5 ms	2.0 ms	2.2 ms
<b>Voltmeter/ammeter measurement accuracy</b> (at 23°C ± 5°C) voltage	Voltage high range	0.05% + 20 mV	0.05% + 25 mV	0.016% + 6 mV
	Voltage low range (5.5 V)	N/A	N/A	0.016% + 1.5 mV
	Current high range	0.1% + 4 mA	0.10% + 8 mA	0.04% + 160 µA
	Current low range ( <sup>2</sup> 100 mA, at 0 - 7 V)	N/A	N/A	0.03% + 15 µA
	( <sup>2</sup> 100 mA, at 0 - 50 V)	N/A	N/A	0.03% + 55 µA
	(≤200 µA)	N/A	N/A	0.5% + 100 NA (Option 2UA)

## Related Agilent Literature

Publication title	Publication type	Pub number
<i>Agilent N6705A DC Power Analyzer</i>	Data sheet	5989-6319EN
<i>Powering DC-to-DC Converters Using the Agilent N6705A DC Power Analyzer</i>	Application note	5989-6452EN
<i>Biasing Multiple Input Voltage Devices in R&amp;D</i>	Application note	5989-6454EN
<i>FPGA Circuit Design: Overcoming Power-Related Challenges</i>	Application note	5989-7744EN
<i>Simulating Power Interruptions for DC Input Devices</i>	Application note	5989-6455EN

## Remove all doubt

Our repair and calibration services will get your equipment back to you, performing like new, when promised. You will get full value out of your Agilent equipment through-out its lifetime. Your equipment will be serviced by Agilent-trained technicians using the latest factory calibration procedures, automated repair diagnostics and genuine parts. You will always have the utmost confidence in your measurements.

Agilent offers a wide range of additional expert test and measurement services for your equipment, including initial start-up assistance, onsite education and training, as well as design, system integration, and project management.

For more information on repair and calibration services, go to:

[www.agilent.com/find/removealldoubt](http://www.agilent.com/find/removealldoubt)



### Agilent Email Updates

[www.agilent.com/find/emailupdates](http://www.agilent.com/find/emailupdates)

Get the latest information on the products and applications you select.



### Agilent Direct

[www.agilent.com/find/agilentdirect](http://www.agilent.com/find/agilentdirect)

Quickly choose and use your test equipment solutions with confidence.

[www.agilent.com](http://www.agilent.com)

For more information on Agilent Technologies' products, applications or services, please contact your local Agilent office. The complete list is available at:

[www.agilent.com/find/contactus](http://www.agilent.com/find/contactus)

#### Americas

Canada	(877) 894-4414
Latin America	305 269 7500
United States	(800) 829-4444

#### Asia Pacific

Australia	1 800 629 485
China	800 810 0189
Hong Kong	800 938 693
India	1 800 112 929
Japan	0120 (421) 345
Korea	080 769 0800
Malaysia	1 800 888 848
Singapore	1 800 375 8100
Taiwan	0800 047 866
Thailand	1 800 226 008

#### Europe & Middle East

Austria	01 36027 71571
Belgium	32 (0) 2 404 93 40
Denmark	45 70 13 15 15
Finland	358 (0) 10 855 2100
France	0825 010 700* *0.125 €/minute
Germany	07031 464 6333** **0.14 €/minute
Ireland	1890 924 204
Israel	972-3-9288-504/544
Italy	39 02 92 60 8484
Netherlands	31 (0) 20 547 2111
Spain	34 (91) 631 3300
Sweden	0200-88 22 55
Switzerland	0800 80 53 53
United Kingdom	44 (0) 118 9276201

#### Other European Countries:

[www.agilent.com/find/contactus](http://www.agilent.com/find/contactus)

Product specifications and descriptions in this document subject to change without notice.

© Agilent Technologies, Inc. 2009  
Printed in USA, August 21, 2009  
5990-4043EN



**Agilent Technologies**